



INSTRUCTION MANUAL

Product features: Folding Tray Table

Top dimensions: 50 x 30 cm

Overall dimensions: 62.5 x 30 x 25 cm

Material: bamboo

How to use: Lift the table top to unfold it. Make sure the table legs are fully extended and locked in place.

Warnings: Read this instruction manual before use and keep it for future reference. Use the product as intended. Place the table on a level and stable surface so that it does not tip over and cause damage to your body or property. The table is not designed to hold heavy objects for long periods of time. Do not wash in the dishwasher. Do not use in the microwave oven. Do not immerse in water. Clean with a slightly dampened cloth. Do not use sharp objects or strong detergents for cleaning. Do not use a damaged product. Avoid sharp pulling or movement of the table to avoid damage and to keep it stable. Do not expose the table to extreme weather conditions, which may affect the quality of the bamboo. The table is designed for indoor use. Avoid using it outside, especially in the rain. The table is not intended for sitting. Avoid kneeling or standing on it to avoid the risk of falling and injury.

