

105G双铜

size:350x100/mm


100/mm

350/mm



INSCUP1 Masturbator Instructions

Sketch Map



1. Protective Lid 杯蓋
2. Usage Entrance 使用入口
3. Button And Indicator Light 按鍵及指示燈
4. Hold-down nut of suction cup 吸盤固定螺母
5. Charge Hole 充電插孔

CN

介紹

感謝您使用OTOUCH的產品!為您更好地使用本產品,請仔細閱讀本說明書。

包裝清單

1 x 自慰杯 1 x 充電線 1 x 說明書

技術參數

材料: 矽膠, ABS, TPE
 振動模式: 7種振動模式
 加熱模式: 1檔加熱 43±5°C
 工作電壓: 3.7V
 電池容量: 1000mAh
 工作噪音: <60dB
 使用時間: >60分鐘(滿電狀態)
 防水等級: 整機不防水(取出膠體清洗)

按鍵功能




1. 長按2秒開/關機。
2. 單按開啟或切換振動模式。
3. 雙擊暫停/恢復振動模式。
4. 三連擊開啟/關閉加熱功能。

使用說明

1. 首次使用產品前請先充電,請將配置的USB充電線正確插入產品的充電孔,然後您可以選擇使用電腦USB接口或帶USB接口的手機充電器為產品充電。正常充電時,產品指示燈會閃爍提示;當電池充滿時,指示燈會長亮。

2. 產品使用前應做適當的清潔,(請注意杯體內不能沖洗,請取出膠體清洗。)可用溫水或專用清潔劑擦拭使用部位,並用幹毛巾輕輕擦幹。
3. 在器具上或人體塗上適當的潤滑劑,以達到健康愉快的效果。
4. 每次使用後,請將軟膠套從杯體中取出。用溫水和除菌香皂清洗後,再用清水洗幹淨,最後用幹毛巾輕輕擦幹水份,自然風幹保存。
5. 請保存在清潔幹淨避免陽光直射並且兒童接觸不到的地方。

清洗步驟




1. 逆時針旋轉鬆開軟膠套固定圈,用力把軟膠套拔出來。




2. 軟膠套洗淨後用幹毛巾擦幹水份,自然風幹。

! 請注意杯體內不能沖洗。



3. 將軟膠套塞回杯體中,軟膠套底部通過磁鐵固定。



4. 順時針旋轉鎖緊軟膠套固定圈。

健康與安全預防措施

- 請勿在靠近水的地方充電。
- 如果USB線損壞,請勿充電。
- 請勿在產品上使用其他充電線。
- 設備充電時不可運作,請勿在充電期間開機。
- 請勿將產品放入洗碗機或微波爐中,以免產品損壞。
- 本品僅作為情趣用品出售,不可作為醫療用品預防或治療任何疾病,避免對身體造成不利的影響。
- 本產品不適用於腫脹或發炎的皮膚區域,避免傷害身體或加重不適。
- 請勿讓孩子使用本產品。
- 如果患有糖尿病或其他病癥,請在使用前諮詢醫生。
- 如果產品的任何部件有損壞,請勿使用。
- 本產品僅適用水溶性潤滑劑。

For instructions in other languages, visit:
www.otouch.com/download-center



RoHS CE UK CA

Brand Owner: SHILOSH International (Hong Kong) Co., Limited.
 ADD: Unit 4,7/F,bright way tower ,NO.33 Mongkok road, kowloon, Hongkong

品牌商: 私樂仕國際(香港)有限公司
 地址: 香港九龍旺角道33號凱途發展大廈7樓04室

EN

Introduction

Thank you for using OTOUCH's products! For better use of this product, please read this manual carefully.

Packing list

1 x Masturbator 1 x Charging cable 1 x Instructions

Technical Parameter

Materials: Silicone , ABS, TPE,
 Vibration Mode: 7 Modes
 Heating Mode: One level , 43±5°C
 Working Voltage: 3.7V
 Battery Capacity: 1000mAh
 Working Noise: <60 dB
 Duration: > 60 minutes(under full power)
 Waterproof: Not rated for waterproof (Remove the penis sleeve to rinse thoroughly)

Keyboard Function




1. Press for two seconds to turn the power supply on or off.
2. Single press the button to turn on/switch the vibration modes.
3. Double-press the button to pause/resume vibration modes.
4. Quick press 3 times to turn on/off the heating modes.

User instructions

1. Before using the product for the first time, please ensure it is fully charged. Insert the provided USB charging cable correctly into the charging port of the product. You can choose to charge the product using a computer's USB port or a USB charger with a compatible interface. During normal charging, the product indicator light will flash intermittently, and when the battery is fully charged, the indicator light will stay on continuously.
2. It is recommended to clean the product before use (note: do not rinse the cup body if it is not waterproof, remove the penis sleeve for cleaning). Wipe the surface of the cup body with warm water or a specialized cleaner for the intended areas of use, and gently dry it with a towel.
3. Apply an appropriate amount of water-based lubricant to the sleeve or on the body for a pleasant and comfortable experience.
4. After each use, remove the penis sleeve from the cup body. Wash it with warm water and antibacterial soap, rinse thoroughly with clean water, and gently dry it with a towel. Allow it to air dry naturally for storage.
5. Store the product in a clean and dry place, away from direct sunlight and out of reach of children.


Cleaning Steps




1. Rotate counterclockwise and release the penis sleeve fixation ring, then forcefully pull out the penis sleeve.



2. After cleaning the penis sleeve, wipe the water with a towel and air dry naturally.



3. Insert the penis sleeve back into the cup, with the bottom of the sleeve secured by the magnet.



4. Rotate clockwise to lock the penis sleeve fixation ring.

! Note: The masturbation cup can not be rinsed.

折叠线

折叠线

折叠线

折叠线