Operation method
Usage:
1.Plug the receiver into the microphone input port of the speaker oramplifier
2.Turn on the receiver power switch.
3.Turn on the handheld microphone (install two AA batteries)

Matters needing attention:
1. Do not place the product in water or fire.
2.Do not use it in places with signal interference, such as hospitals and airports.
3.Please do not disassemble the product without authorization,otherwise the warranty qualification will beost.
4.If the product is faulty, please contact the dealer

Warranty description:
The warranty period and "three guarantees" period of validity of the product from the date of sale, failure of the product during normal use can be based on the "three guarantees"
Provision for repair, replacem ent and return. During the warranty period, you can enjoy free maintenance service in the technical service center of each dealer according to the content of this warranty clause. In the warranty (including the "three quarantees" period of validity) the following conditions will be implemented
Paid maintenance service, while not enjoying the three guarantees service:
1. The original valid warranty card and valid invoice are not allowed
2. Items such as the date of purchase, name of sales unit (valid withseal) or warranty card are not com pletely filled in.
3.Failure or damage caused by force majeure.
4. Failure and damage caused in transportation and loading and unloadina.
5.Failure caused by failure to operate according to the usage method and precautions written in the manual.
6. Failure caused by disassembly, maintenance or modification of the product without authorization of the company.

Portable universal wireless microphone

Operating instruction

The user instructions

Dear users, thank you for buying our products!
Please read this manual carefully before using the product, and operate the product correctly according to the instructions. Please keep this manual properly for future reference.

Handheld transmitter function

1.Net head: speak and sing to this place.
2.Status screen: display working status and frequency, etc.
3.Power switch: Turn on and off power.
4.Battery cover: Unscrew the tail tube to insert two AA batteries.
5.Tail cover: At the radio wave transmitting antenna, try notto carry it by hand when using it.

Receiver function

1. Audio output:6.35mm male head.
2. Power switch: Push up to open, push down to close.
3.Power indicator light: The receiver displays green when it is turned on, red when it is charging, and the red light is off when it is fully charged.
4. Charging interface: Use data cable to charge.
5. Microphone indicator light: When the microphone receives the signal, the signal light will be on.
6. Receiving antenna: To receive the signal from the transmitter.
7.Battery cover: Built-in 18650 replaceable battery,open the battery cover and replace directly.