

gatson

MusicalBoxing Pro



Please read the instruction before using

FC CE

Technical Data:

Input: DC 5V Power: 5W Working Voltage: 5V
Carton: 52*52*10 cm N.W/G.W.: 2.5kg/ 2.8kg
Battery: 2000mA
Bluetooth Name: YX-BOXING-XXXX

Charging:

Use the mobile phone charger (5V/1A-2A) to charge via the attached cable link. Mounting Boxing Pro should be considered close to the wall socket position




Type C

Installation:



A. Peel off the white film behind the black adhesive tape and stick to the wall.

Operation:




1. On/Off: Long press the "On/Off" button for 2 seconds to switch the machine on and off. After no key operation and strike for one minute, the boxing light switches to the music flashlight mode, the key operation or strike automatically exits, if the Bluetooth is not connected, it will automatically shut down after three minutes.
2. The Bluetooth is standby for bluetooth connection when the machine is powered on. Bluetooth name: YX-BOXING-XXXX .
3. Turn On and Off the percussion audio: Double-click the "On/Off" button, and the display "ON" is turned on, and the display "OF" is turned off.
4. Mode: Press the "Mode" key to switch mode, P01-P09 cycle switch. P01 is random mode, and P02-P09 is preset sequence.
5. Speed & Sensitivity: Press the "Speed" key to switch the preset fixed speed(H01-H06) or Sensitivity(HA1-HA3), which is variable speed.
6. Volume: Long press the "Mode" key to increase the volume, long press the "Speed" key to decrease the volume.

EN-01



B. Cut out right area on white film and stick the short Velcro hook, and stick the long Velcro loop on the wll. Stick the hook and loop together.



C. Fix it with the screw and the stator.

Caution:

1. Don't use it within 30 minutes after a meal.
2. It should not be used during prgnancy or menstruation.
3. It is forbidden being washed, can be wiped with a rag.
4. It should be charged when it is power off automatically. Should be charged every 15 days.
5. It should be charged for 30 minutes after receiving it.
6. It is recommended to wear boxing gloves.
7. It is prohibited to disassemble the product without permission.

Made in China

EN-02

EN-03

gatson

Musical Boxing Pro



Lees de instructies voordat u het product gebruikt



Technische gegevens:

Input: DC 5V Vermogen: 5W Werkspanning: 5V
Doos: 52*52*10 cm N.W/G.W.: 2,5kg/ 2,8kg
Batterij: 2000mA
Bluetooth-naam: YX-BOXING-XXXX

Opladen:

Gebruik de mobiele telefoonlader (5V/1A-2A) om op te laden via de bijgevoegde kabelverbinding. Montage Boxing Pro moet worden overwogen dicht bij de stopcontactpositie



Type C


Installatie:



A. Trek de witte folie achter de zwarte tape los en plak de folie op de muur.

NL-02

Werking:



1. Aan/Uit: Houd de "Aan/Uit"-knop 2 seconden lang ingedrukt om de machine aan en uit te zetten. Na een minuut geen toetsbediening en slag, schakelt de bokslamp over naar de muzieklampmodus, de toetsbediening of slag wordt automatisch afgesloten, als de Bluetooth niet is verbonden, wordt deze na drie minuten automatisch uitgeschakeld.
2. Bluetooth staat stand-by voor Bluetooth-verbinding wanneer het apparaat is ingeschakeld. Bluetooth-naam: YX-BOXING-XXXX.
3. De percussie-audio in- en uitschakelen: Dubbelklik op de "Aan/Uit"-knop. Het display wordt op "AAN" gezet en het display op "OF" wordt uitgezet.
4. Modus: Druk op de "Modus"-toets om de modus te wisselen, P01-P09 cycluswissel. P01 is de willekeurige modus en P02-P09 is de vooraf ingestelde volgorde.
5. Snelheid en gevoeligheid: Druk op de toets "Snelheid" om te schakelen tussen de vooraf ingestelde vaste snelheid (H01-H06) of de gevoeligheid (HA1-HA3), wat variabele snelheid is.
6. Volume: Houd de "Mode"-toets lang ingedrukt om het volume te verhogen, houd de "Speed"-toets lang ingedrukt om het volume te verlagen.

NL-01



B. Knip het juiste gebied uit de witte film en plak de korte klittenbandhaak, en plak de lange klittenbandlus op de muur. Plak de klittenband aan elkaar.



C. Bevestig het met de schroef en de stator.

Voorzichtigheid:

1. Gebruik het niet binnen 30 minuten na een maaltijd.
2. Het mag niet gebruikt worden tijdens de zwangerschap of menstruatie.
4. Het is verboden om het te wassen, het mag wel met een doekje worden afgeveegd.
3. Het moet worden opgeladen wanneer het automatisch wordt uitgeschakeld. Moet elke 15 dagen worden opgeladen.
5. Na ontvangst dient de betaling 30 minuten in rekening te worden gebracht.
6. Het dragen van bokshandschoenen wordt aanbevolen.
7. Het is verboden om het product te demonteren zonder toestemming.

Gemaakt in China

NL-03