## SAFETY INSTRUCTION

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference

- The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation.
- Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, maintenance or repair work is undertaken.
- Exterior lighting must not be installed during rain.
- 5. Take account of the minimal separation distance from other objects and the room required around the fitting.
- If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.

-Earth

- Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components
- 10. Take account of all available technical information.
- Take note of the symbols when connecting wires:
- N = Neutral L = Live 12. Meaning of symbols:

For indoor use only, where direct contact with water is impossible

IPXX This icon indicates the level of water-proof and dust-proof

Protection Class I: the fitting must be earthed

Protection Class II: the fitting is doubled insulated and does not require earthing

Protection Class III: the fitting is low voltage

Minimum distance from lighted objects (meters)

Only the self-shielded halogen lamp should be used with the luminaire

Strip the wire to the indicated length (mm); different items require different length

Connect using the specified coble; different items require different cobles

The type of lamp and maximum size and wattage indicated in each lighting unit must not be exceed; different items require different kind of light sources with different bulb icons


The armature is designed to work only with the indicated voltage. Different items require different working voltage.

The luminaire can be used in combination with a dimmer

The reference light angle and light space of the luminaire

This luminaire cannot be disposed together with normal domestic waste in standard rubbish can, but you have to bring it to a staging area for electrical waste

## 11. Take note of the symbols when connecting wires:



	(DE)	(GB)	(FR)	(NL)	IPL1	(NO)	(DK)
ι	Sponführender Leiter	Uve conductor	Conductour	Sponning- voerendo draud	Przewist prodowy	Strømførende linter	Strømførende leder
4	Schutzleiter	Earth conductor	Conducteur de protection (terre)	Aardkabel	Proposid uziemiający	Jordledningen	Jordledningen
N	Neutralietter	Meutral conductor	Conductour	Nulloider	Promod	Naysralleder	Neutralleder

	(58)	(11)	(0)	(ES)	(CI)	(PT)	(GR)
L	Strömförande ledare	Virtajohdin	Conductore sotto tensione	Conductor de corriente	Vodič pod napětím	Condutor vive	Ρενμιποφόρος πευεός
(1)	Skyllistedare	Suspiolsdin	Conduttore di terra	Conductor de protección	Ochranný vodať	Condutor de terre	Αγωγός γείωσης
N	Neutralisdare	Mallajohdin	Conduttors neutro	Conductor	Neutrální yodíř	Condition	Ουδέτερος πρωχός



1

D-140

## INSTRUCTION MANUAL



















Carcass HL Long Black 93608





