



# Karaoke microphone

## USER'S MANUAL


### Preface

Thank you for purchasing this product. Please read the manual carefully before using this product and store it for future reference.

### Warning and safety instructions

- Only use the microphone for its intended purposes.
- Do not store this product in a humid, dusty or high temperature environment.
- Do not expose this product to rain, water or moisture to prevent an electric shock.
- Do not remove the cover or attempt to disassemble this product, this can damage the device and present a safety hazard.
- Turn off the microphone when not in use.

### Microphone buttons



### Product specifications

Model: iMoshion Karaoke Microphone  
Battery capacity: 2200 mAh

### Buttons explanations

1. Power button: Long press to turn on or off. Short press to activate or deactivate karaoke mode: the song's original voice sounds will be lowered.
2. Mode button: Long press to activate magic sound mode, short press to cycle through the 4 magic sounds. Long press again to deactivate magic sound mode and go back to bluetooth mode.
3. Previous button.
4. Next button.
5. Play/pause button.
6. Volume switch: adjust microphone volume.
7. Echo switch: adjust microphone echo.
8. Music switch: adjust music volume.

### Bluetooth mode:

1. Long press the power button to turn on the device, the blue light will start flashing.
2. Turn on the bluetooth on your mobile device and search for iMoshion Karaoke Microphone. Click and pair the device, the microphone will say bluetooth connected and the light turns blue.
3. Play music through your favourite music playing app and adjust the volume on your mobile device.
4. If you want to record your singing open the recording app on your mobile device and follow the app's instructions to record. The app will record the sound from the microphone.

### AUX mode:

1. Long press the power button to turn on the device.
2. Plug in the micro usb cable in to the device and the AUX cable into the device where you want to play music from. The microphone will say aux input mode.
3. Play music through your favourite music playing app and adjust the volume on your connected device. If you want to record your singing open the recording app on your mobile device and follow the app's instructions to record. The app will record the sound from the microphone.

### TF mode:

1. Long press the power button to turn on the device.
2. Insert a TF card into the microphone and play songs from the card directly.

### How to charge:

1. Use the micro USB cable to charge the microphone, the red light will turn on indicating that the microphone is charging.
2. When the microphone is fully charged the red light will turn off.