

Angel Juicer

SINCE 1982

Product Name: Electric Juice Extractor

Model No: **Angelia 5500**

Voltage: **AC220V/180W**

Frequency: **50Hz**

Proper Electricity Consumed:

S/N: 



Made in Korea

General Safety Instructions

1. To protect against electric shock, do not immerse cord, plug or water or any other liquid.
2. Careful supervision is necessary, when this appliance is used. Do not let the children use the appliance.
3. Always use the food pusher provided with the juicer to push fruits and/or vegetables into the feeding chute.
4. Unplug power cord from the outlet, when the juicer is not used.
5. Do not run the appliance, when run without food or overfilled.
6. Do not force too mush fruits and/or vegetables through the chute too fast.
7. Do not hang the electrical cord over the edge of the counter, in a drawer, or lay on a burner or other hot surface.
8. Recommended circumstance temperature is -10°C.
9. The appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, unless they have been given supervision and instruction on the use of the appliance by a person responsible for their safety.
10. Children should be supervised to ensure they do not use the appliance.