

Warranty

30 Day Limited Warranty
Our watches are covered by a limited 30 day warranty. Warranty does not cover normal "wear and tear".

PLEASE OPEN YOUR MERCHANDISE WITHIN (3) DAYS OF RECEIVING THE MERCHANDISE.

PLEASE CONTACT US IMMEDIATELY TO REPORT ANY DAMAGES.

PLEASE KEEP ALL THE ORIGINAL PACKAGE MATERIALS FOR ALL DAMAGE CLAIMS THAT IF YOU MISS OR LOST ANY PARTS OF THE ORIGINAL PACKAGE MATERIALS INCLUDING BOX/FORMS AND ANYTHING ELSE THAT CAME WITH THE ORIGINAL PACKAGE.

FAQ

Q: I can't find my award medal!
A: The award medal is embedded in the foam packaging in a white box.

Q: My watch does not wind my watch.
A: The watch should be fully wound previous to being placed in the watch box. The watch should be wound with the manual on the winding information.

Q: My watch does not fit around the pillow.
A: Please refer to the pillow (S) from the slide on the watch box. You should be able to insert your watch with the pillow into the slide on the watch box. If you have a smaller size strap or bracelet, you can remove the stuffing from the pillow to accommodate for the size.

Warranty

30 Day Limited Warranty
Our watches are covered by a limited 30 day warranty. Warranty does not cover normal "wear and tear".

PLEASE OPEN YOUR MERCHANDISE WITHIN (3) DAYS OF RECEIVING THE MERCHANDISE.

PLEASE CONTACT US IMMEDIATELY TO REPORT ANY DAMAGES.

PLEASE KEEP ALL THE ORIGINAL PACKAGE MATERIALS FOR ALL DAMAGE CLAIMS THAT IF YOU MISS OR LOST ANY PARTS OF THE ORIGINAL PACKAGE MATERIALS INCLUDING BOX/FORMS AND ANYTHING ELSE THAT CAME WITH THE ORIGINAL PACKAGE.

FAQ

Q: I can't find my award medal!
A: The award medal is embedded in the foam packaging in a white box.

Q: My watch does not wind my watch.
A: The watch should be fully wound previous to being placed in the watch box. The watch should be wound with the manual on the winding information.

Q: My watch does not fit around the pillow.
A: Please refer to the pillow (S) from the slide on the watch box. You should be able to insert your watch with the pillow into the slide on the watch box. If you have a smaller size strap or bracelet, you can remove the stuffing from the pillow to accommodate for the size.

Automatic Watch Winder

Adapter Inlet



Power Switch *Note: 4 & 8 models have two switches

(Bottom of Watch Winder)

Battery Compartment



Battery: Remove the battery cover on the bottom of the watch. Insert 2pcs 1.5V battery to the strips. Replace the cover.

Automatic Watch Winder

Adapter Inlet



Power Switch *Note: 4 & 8 models have two switches

(Bottom of Watch Winder)

Battery Compartment



Battery: Remove the battery cover on the bottom of the watch. Insert 2pcs 1.5V battery to the strips. Replace the cover.

Features

- Fine wood & veneer construction
- Polished finish for high gloss
- Delicate faux suede interior
- Soft touch leather exterior
- Works with included AC Adapter & Batteries *(Batteries on select models only)
- Fuzzy logic bi-directional winding provided by computer board

Rotation Mode

Handle Free winding
The watch will automatically rotate bi-directionally and pause intermittently.

Rotates for two minutes in one direction then pauses for six minutes. Resumes rotation in opposite direction for two minutes then pauses for six minutes. Program continues until power is switched off.

Features

- Fine wood & veneer construction
- Polished finish for high gloss
- Delicate faux suede interior
- Soft touch leather exterior
- Works with included AC Adapter & Batteries *(Batteries on select models only)
- Fuzzy logic bi-directional winding provided by computer board

Rotation Mode

Handle Free winding
The watch will automatically rotate bi-directionally and pause intermittently.

Rotates for two minutes in one direction then pauses for six minutes. Resumes rotation in opposite direction for two minutes then pauses for six minutes. Program continues until power is switched off.