

Artikel is niet een spel, a garder hors de la portée des enfants. Enregistrer cette information soigneusement.
L'ensemble d'éclairage a 3 fonctions: 1. "TIMER" pour allumer pendant 6 heures et éteint pendant 18 heures, 2. "ON" pour allumé en continu, 3. "OFF" pour éteint en continu.
EN: Artikel is niet für Dekorationszwecke geeignet. Artikel ist kein Spielzeug. Für Kinder nicht zugänglich Aufbewahren. Speichern Sie diese Informationen sorgfältig. Dieses Beleuchtungsset hat 3 Einstellungen: 1. „TIMER“ = automatisch 6 St. an und 18 St. aus, 2. „ON“ = Dauerbetrieb, 3. „OFF“ = dauerhaft aus. EN: Product is suitable for decoration purposes only. Product is not a toy, keep out of reach of children. Save this information carefully. This light set has 3 functions: 1. "TIMER" for switching the light on/off automatically (6 hours on and 18 hours off); 2. "ON" for continuously switched on; 3. "OFF" for continuously switched off.



Itemnr.: 675461
CBD - P.O.BOX 16
1738 ZG - WAARLAND (NL)



8 713619 313950

3 x AA (Not included)

22