

INSTRUCTION MANUAL



FEATURE:

- One dimmer Have two independent rotary to control two separated way.
- Only two wire connection, no neutral required, easy for installation.
- Compatible with incandescent bulb, dimmable LED lamps, minimum load 3W.
- Short-circuit, over-load, over temperature protection design, protect connection safety and make sure dimmer can survive in wrong wiring or failure load.
- SELF RESETTABLE function, no need change fuse to reset dimmer when Short-circuit, over-load, over temperature protection happened.


SPECIFICATION:

Working Voltage	220-240V/50Hz
Dimming Mode	Trailing Edge
Load compatibility Limited	
Halogen lamps	2 x 3-150W
Incandescent lamps	2 x 3-150W
Dimmable LED lamps	2 x 3-75W
Dimmer safety protection	
Over-load protection	YES
Over-temperature protection	YES
Short-curt protection	YES
Working Temperature	-20°C - 40°C
IP Level	IP20

INSTALLATION

1. Make sure the electricity is switched off before any operation ,connect the wire as WIRE CONNECTION.
2. Install the dimmer into the Junction box
3. When connection well, use two independence rotary to control two separated way.
4. Switch on the electricity, push rotary button to ON and OFF, turning rotary to adjust brightness level.
5. Adjust two independent Min to set two separated way's minimum brightness level to solve lamps flashing.
6. When short-curt or overload happened in any connection, the whole dimmer will stop working to protect dimmer and connection safe, when short-curt or overload problem been fixed, after 30 seconds, turn on the electricity and dimmer again, dimmer will reset and working well.
7. Finished all setting, fit on the wall plate kit with dimmer.

WIRE CONNECTION:



SAFETY NOTE:

All works must be under electricity disconnected, all operation only carried out by certified electrician, under the national valid regulations.

Observance instructions manual is parts of guaranty, wrong operation without observance instructions manual may lead to equipment damaged, fire or other dangers.

The warranty will be expired if the dimmer is opened or tampered, any doubt when installation, please check with seller before operation.