

JTC



**USER'S
MANUAL**

OmniBlend V

**HEAVY DUTY
PROFESSIONAL
BLENDER**

MODEL: TM-800A

POWER

QUICKLY PURÉES
AND BLENDS EVEN
THE TOUGHEST
INGREDIENTS.

DURABILITY


RUGGED
CONSTRUCTION
OUTLASTS OTHER
BLENDERS 5 TO 1

VERSATILITY

SPEED CONTROL
ALLOWS YOU TO
PURÉE, BLEND,
CHOP OR GRIND.

AUTOMATIC


PRE-PROGRAMMED
CYCLES SAVES YOUR
TIME; JUST ONE TOUCH
EASY OPERATION.



E ENGLISH

omniblender.ca

PARTS&FUNCTIONS



OPERATING FROM CONTROL PANEL (QUICK GUIDE)

1. Insert the power plug into an electric outlet.
2. Turn on the main power switch.
(Press from the surface water proof transparent cover)
3. Place the properly filled blender jar on the base, make sure the jar is seated all the way down and attach the lid securely.
4. Manual operation: Select HIGH, MED, LOW or PULSE (the fastest speed when depressing down the switch and holding down as long as needed).
5. Automatic cycle operation: Press 35", 60" or 90" for automatic blend & shut off.
6. The red LED display during operation, a long-beep sound reminds finish of the automatic cycle operation.

NOTE: To stop the operation at any time by touch any button.

OPERATING INSTRUCTIONS

1. Always place some liquids into container when crushing ice cubes.
2. Never operate the blender while the container is empty.
3. Do not attempt to remove or replace while the motor is running.
4. Never run motor while container is not in place.
5. As this blender is a high speed unit, blending times are greatly reduced from normal blenders; long time overuse will hot up the food or beverage.
6. Place blender base on a flat, clean & dry surface.
7. If the drink is mixing well but has not had enough time for complete blending, try a longer cycle or touch and hold the PULSE button for required extra Blending time.
8. Make sure the drive shaft on the jar is fully engaged into the drive socket and that the blade is firmly affixed to the drive shaft.
9. Please wipe all water off the cushion before starting operations. Any water present could be pulled in and will cause damage to the motor!

CLEANING

Warning: Unplug the power cord to ensure safety.

1. Place a little warm water with detergent into container.
Place on lid and switch the Blender on for approximately 10 seconds.
Empty container, rinse and leave upturned on a bench to dry.
(The motor power is very strong, so you can remove most of the residual foods easily by just using warm water and detergent.)
Do not clean inside of container by hand unless cutting unit has been removed.
2. To clean motor base use a slightly damp cloth only. (Never immerse motor base in water)

TROUBLESHOOTING

Warning: Unplug the power cord to ensure safety.

- 1) This blender is fitted with a safety overload switch at the rear of the machine. If the motor overload, the power will be cut automatically to ensure safety, please check and remove the unsuitable blending goods, then press the reset button (on the bottom) to start again.
- 2) Check the power cord is attached correctly to the blender.
- 3) If your blender is still not functioning correctly, please contact with your purchased shop or nearest distributor, please refer to the warranty card, do not attempt to open and repair by yourselves.
- 4) If the power cord damage, it must be replaced or repaired by a qualified electrician or engineer in order to avoid a hazard.
- 5) The cutting unit will be worn-out after long-term use, if the water leak out, it must be replaced, please contact with your purchased shop, distributors, or our after service centers. **Warning: Blades are sharp, handle carefully.**

IMPORTANT SAFEGUARDS

- Read all instructions.
- To Protect against risk of electrical shock do not put blender base and power supply cord in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contacting moving parts. - Do not operate the appliance with a damaged cord or after the appliance malfunctions, or is dropped or damaged in any manner.
- Return appliance to the nearest authorized service facility for examination, repair or electrical or mechanical adjustment.
- Do not use outdoors, this appliance was for household use only.
- Do not let cord hang over edge of table or counter.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
- Blades are sharp. Handle carefully.
- To reduce the risk of injury, never place cutter-assembly blades on base without jar properly attached; never take the jar away during operation.
- Always operate blender with cover in place.
- The use of attachments, including canning jars, not recommended by the manufacturer may cause a risk of injury to persons.
- Container should not be more than 2/3 full while blending.
- Do not process for more than 1 minute after mixture starts circulating, over-processing will cause the mixture in the container to overheat.
- Only use the blender on a flat, level, stable and dry surface.
- Always ensure that the container is properly seated in position and the container lid (complete) is properly fitted and secured before switching on the blender, place hand on top of lid when starting machine and during operation.
- Take care when blending hot liquids, do not fill container, the maximum quantity is to the 1 litre mark. Always start motor on low speed or auto mode.
- Ensure that the lid is located under raised projections on container before switching on.
- The lid can only be removed when the blender is switched off and cutting unit has ceased turning.
- Never leave the blender unattended when in use.

SAVE THESE INSTRUCTIONS