







Wireless Keyboard



00051855
00053801
00053815
Version 1/2011



für/for SONY PS3

XMB™ menü

- Game
- Network
- PlayStation®Network
- Friends

network menü



- Internet Browser
 - Basic operation of the Internet browser
 - Browse mode / window mode
 - Browse mode menu
 - Window mode menu
 - Change the display size of a Web page
 - Using short keys / mouse / keyboard
 - Load / Download
 - Internet Browser User Agreement
- Internet Search

Using short keys / mouse / keyboard

Using short keys
You can operate directly with the buttons of the wireless controller without the menu. Operation available vary between browse mode and window mode.

Browse mode

- X button: Open the link.
- X button (hold down): Open the link in a new window.



hama
Hama GmbH & Co. KG
D-86651 Monheim/Germany
www.hama.com

All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.



