

Operating Instructions: The external flexible cable or cord of this luminaire co the cord is damaged, the luminaire shall be destroyed. Do not connect the ch while it is in the packing. The lamps are not replaceable.





Input: 230-240V ~ 50/60 Hz. Output: 4,5V === 444 mA - 2VA

Transformator -Transformateur Transformator - Transformer