


**aanwijzing:** Het snoer van deze verlichtingsset kan niet worden vervangen. Wanneer de verlichtingsset worden vernietigd. Sluit het snoer niet aan op het stroomnet wanneer die in de verpakking is. Deze verlichtingsset heeft 3 functies: 1. "ON" voor continu aan, 2. "TIMER" voor continu uit.

**Emploi:** Le cordon de cet ensemble d'éclairage ne peut pas être remplacé ; si le cordon doit être détruit. Ne pas brancher l'alimentation tant que la guirlande est toujours dans son emballage. Cet ensemble d'éclairage a 3 fonctions : 1. "ON" pour allumé et continu, 2. "TIMER" pour éteint pendant 16 heures, 3. "OFF" pour éteint continu.

**isanleitung:** Das flexible Kabel dieses Beleuchtungssets kann nicht ausgetauscht werden. Das flexible Kabel dieses Beleuchtungssets kann nicht ausgetauscht werden. Dieses Beleuchtungsset hat 3 Einstellungen: 1. "ON" für dauerhaft an, 2. "TIMER" für 16 Stunden aus, 3. "OFF" = dauerhaft aus.

**g Instructions:** The external flexible cable or cord of this luminaire cannot be replaced. Do not connect the chain to the power supply while it is in the packaging. This lighting set has 3 functions: 1. "ON" for continuously switched on, 2. "TIMER" for switching the light off for 16 hours, 3. "OFF" for continuously switched off.

5m



Transformator - Transformateur  
Transformator - Transformator  
**IP44**

Input: 220-240V - 50 Hz  
Output: 31V ~ 116mA - 3,6VA  
CBD - P.O.BOX 16  
1738 ZG - WAARLAND (NL)