



De afwijking van de afmetingen van het verlichtingsset kan niet worden vervangen. Wanneer het snoer beschadigd is, kan het snoer niet worden vervangen. De lampen zijn niet vervangbaar. Deze verlichtingsset heeft 3 functies: 1. "TIMER" voor automatisch 6 uur aan en 18 uur uit, 2. "ON" voor continu aan, 3. "OFF" voor continu uit.

Les dimensions de l'ensemble d'éclairage ne peuvent pas être remplacées, si le cordon est endommagé, il ne peut pas être remplacé. Les ampoules ne peuvent pas être remplacées. Cet ensemble d'éclairage a 3 fonctions pour allumer pendant 6 heures et 18 heures d'arrêt, 2. "ON" pour allumé en continu, 3. "OFF" pour éteint.

Anleitung: Das Gerät, das Kabel und die Lampensets kann nicht ausgetauscht werden; wenn das Kabel beschädigt ist, das Beleuchtungsset zu zerstören, das Kabel kann nicht ausgetauscht werden. Dieses Beleuchtungsset hat 3 en: 1. "TIMER" = automatische 6 Stunden an und 18 Stunden aus, 2. "ON" = Dauerbetrieb, 3. "OFF" = dauerhaft aus.

Instructions: The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire will be destroyed. The light set has 3 functions: 1. "TIMER" for switching the light automatically (6 hours on and 18 hours off); 2. "ON" for continuously switched on; 3. "OFF" for continuously switched



3 x AA (Not included)

Itemnr.: 231512



8 713619 347030

CBD - P.O. BOX 16
1738 ZG - WAARLAND (NL)

   **IP44**