



Manual
 Gebruiksaanwijzing
 Gebrauchsanweisung
 Mode d'emploi
 Bruksanvisning
 Brugsvejledning
 Käyttöopas
 Uživatelská příručka
 Používateľská príručka
 Εγχειρίδιο χρήσης
 مدد دسترس لى لى

XR101




#MOREENERGY

XTREME SERIES - Power your adventures

①



- 10.000mAh Li-Polymer / 38,5Wh
- 114x89x25mm
- 540g
- Output:** 1x USB-C PD 18W
2x USB Quick Charge 3.0 18W
- Input:** USB-C PD 18W
- Total output:** 18W single output / 15,5W shared
- Water-resistant (IP65), Built-in flashlight (100 Lumen), USB to USB-C cable, manual




②



③



④



⑤




⑥



- FLASHLIGHT 100LM
- LED POWER INDICATORS
- CHARGING INDICATION:**
Press button 1x
- FLASHLIGHT ON:**
Long click (3 seconds) on button
- FLASHLIGHT OFF:**
Click twice on button
- LIGHT ON LIGHT OFF
- | | |
|---|---------------|
| 4 | POWER 75-100% |
| 3 | POWER 50-75% |
| 2 | POWER 25-50% |
| 1 | POWER 0-25% |

⑦



XTREME SERIES - Power your adventures

