

Durch Betätigen der „Multi-Color“

(EN) Attention

This item is NOT a toy. Children should be supervised when using batteries. For indoor use only. Burning time: 60 hours. On-ions actions may cause the batteries to explode. Do not throw away batteries; dispose of as small chemical waste. Battery operated, t

You should dispose this product in compliance with the regulations for the disposal of electrical and electronic components.

Instruction for using Remote Control:

1. Turn switch on bottom of each tealight into position "on".
2. Use "on/off" button on RC to turn the tealights on/off.
3. Select color by using one of 12 color buttons.
4. Set 4 hrs or 8 hrs timer by using according button. All tealights will turn off after selected time automatically.
5. Select flickering mode by pushing "Mode" button. For steady light push again.
6. Choose color change mode by pushing "Multi color" button.

Hergestellt in China
Made in China
CEPEWA GmbH
Max-Planck-Str. 10 a
D - 61184 Karben

Art. 72753/21030903

