

Use screwdriver to insert screw on
driver not included)

to install batteries (4"AA") Insert
struction. Make sure all batteries are fitted
wise this may result in a short-circuit.


batteries or new and used batteries are not
ose of batteries in fire. Batteries may explode

rechargeable batteries are not to be recharged.
ase of swallowing seek medical attention
mmediately! Changing batteries to be done by
adults. Keep away from children. If the skin or
clothes coming to contact with liquid from
the battery, wash immediately. Exhausted
batteries are to be removed from the
product.

CE



to be charged under adult supervision
from the toy before being charged
laws and regulations of your region
shall be regularly examined for damage
other parts, and in the event of damage
has been repaired. The toy is not
The toy shall only be used with a power
The model number or specification
(e.g.: 5V, 1-2A, DC) for use with the
The toy shall be used with the power
The power supply is not a toy.
Toys liable to be cleaned with liquids
disconnected from the power supply



The toy is only to be connected
to the equipment bearing the
following symbol:

