




Parts of Multi Food Chopper Made of environmental materials.




①




②




③




④




⑤



⑥




⑦




⑧



⑨



⑩



⑪

- ① 14mmX14mm Dicing Blade
- ② 7mmX7mm Dicing Blade
- ③ Egg White Filter
- ④ Ricing Blade
- ⑤ 4mm Shredding Blade
- ⑥ 3mm Shredding Blade
- ⑦ 2mm Slicing Blade
- ⑧ Potato Lattice Blade
- ⑨ Brush
- ⑩ Drain Strainer
- ⑪ Hand Protector

⚠ Notes: Sharp blade cut finger carefully!!!

Please refer to the following instructions:



Dicing blade of 7mmX7mm is available for chili,hams,etc.



Dicing blade of 14mmX14mm is available for cucumbers, pitayas,etc.



Slicing blade of 2mm is available for cucumbers, carrots,etc.




Shredding blade of 4mm is available for lettuces, etc.



Shredding blade of 3mm is available for carrots, radishes,etc.



Lattice blade is available for potatoes, sweet potatoes,etc.



Ricing blade is available for gingers, garlics, radishes,etc.



Egg white filter could separate egg yolk from egg white.



Brush could wipe out food remains.



Drain strainer could drain washed vegetables well.