



MIA™ 2

THE WATERPROOF
USB-LIPSTICK VIBE

PRODUCT DESCRIPTION

The perfect way to keep your pleasure truly to yourself, the USB-rechargeable MIA™ 2 massager possesses hidden power and looks perfectly at home in your purse or bedside drawer.

- **Lipstick-Style Design for Discretion and Secrecy**
The disguised body of MIA™ 2 will keep you confident in your pleasure
- **Sculpted Tip for Accurate Pleasure**
The shape has been specifically molded to target the clitoris for fast, intense climaxes
- **USB-Rechargeable for More Power than Batteries**
The integrated USB charger means you can charge quickly for deceptive strength

SPECIFICATIONS

- **Materials:** ABS Plastic / Silicone
- **Finish:** Glossy
- **Size:** 111 x 22 x 22mm / 4.4 x 0.9 x 0.9in.
- **Weight:** 32g / 1.1oz.
- **Battery:** Li-Ion 70mAh 3.7V
- **Charging:** 1hr at 5.0V 100mA
- **User Time:** Up to 1.5hrs
- **Standby:** Up to 90 days
- **Frequency:** 120Hz
- **Max Noise Level:** <50dB

FEATURES

Fully waterproof and
USB-rechargeable

Easy-to-use controls
to explore 6
vibration patterns

Deceptively strong,
whisper-quiet
vibrations



Body-safe ABS for
smooth sensations

L 111mm/4.37"

Ø 22mm/1.87"

LELO

CONTROLS



- Press **+** to turn on and to increase vibration strength.
- Press **-** to lower vibration strength; hold **-** to turn off.
- Hold **+** for 2 seconds to enable cycling through the different vibration patterns
- Press **+** again to change to the next vibration pattern
- Lock by holding **+** and **-** for 5 seconds; the light will turn off when the device is locked.
- Unlock by pressing for 5 more seconds; the light will turn on when the device is active.

LELO

CHARGING

Always charge LELO massagers before first use

Twist the removable cap to reveal the USB-charger



Ensure that it is clean and dry, and avoid getting water inside the cap

LELO

CHARGING

Insert the USB directly into your computer or charging port

The light will pulsate to indicate that it is charging

When fully charged, the light will emit a steady glow



LELO

HYGIENE & CARE



Use **LELO's Antibacterial Cleaning Spray** before and after each use for total peace of mind.

When cleaning with water, **ALWAYS** use a premium antibacterial solution.

100% Waterproof and Rechargeable Design.

Store your LELO massager in its protective storage pouch between uses.

WARNING: Do not boil or use metal scour. Avoid leaving your LELO in direct sunlight and **NEVER** expose it to extreme heat. Do not use on swollen or damaged skin. Keep your LELO out of the reach of children.

IMPORTANT: For Adult Use Only. Those who may be pregnant, have a pacemaker, diabetes, phlebitis or thrombosis should consult with a medical professional regarding the risk of blood clots before using any personal massage product.




LELO

WARRANTY REGISTRATION

1. Visit **LELO.com** and click **REGISTER/LOG IN** in the top right corner of the screen.
2. Follow the directions to register your product and attach details of your purchase.

Don't forget to take advantage of
LELO's full warranty coverage.



The serial number is on the back of the authenticity card provided with every LELO product.

LELO

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems).

The crossed-out dustbin symbol indicates that this product should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.



* FCC Mark, C-Tick and IC certifications relevant to remote-controlled products only.

Disclaimer: Users of this LELO Product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Further, LELO reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Applicable for ALL products. Model may be changed for improvements without notice.

© 2015 LELOi AB. ALL RIGHTS RESERVED.
LELOi AB, Birger Jarlsgatan 22, 114 34 STOCKHOLM, SWEDEN.
LELO Inc., 4320 STEVENS CREEK BLVD., SUITE #205, SAN JOSE, CA 95129, USA.
DESIGNED AND DEVELOPED BY LELO SWEDEN
MANUFACTURED BY LELO IN CHINA

WEBSITE WWW.LELO.COM - SUPPORT CUSTOMERCARE@LELO.COM

LELO

LELO