



Measurement:

1. RESET key is used.
2. Start the measurement by pressing the "ON" key.
3. Clear all the accounts memory when starting.

Notes:

1. For this precise instrument, please make use of the correct measurement method to avoid the influence on its measuring accuracy.
2. If the instrument do not work after pull out battery again.

