Care and using instructions

Battery Installation:

- Unscrew the upper cap with anti-clockwise direction and remove it from the body.
- Fill 6x "AAA" batteries into the battery compartment as per the picture showing.
- Put the upper cap back to the body and turn it to fix with clockwise direction.

Fill the pepper corns:

- Unscrew the lower part of transparent chamber with clockwise direction and remove it from the body.
- Fill the pepper corns or sea salt into the chamber.
 Don't over fill. keep the pepper corns or sea salt 80% full in the chamber as maximum limit.
- Replace the chamber to the body and unscrew it to fix.

Operating your pepper mill:

- Turn it over your gravity pepper mill to start working
- Adjust the top black adjuster to grind your pepper corns or sea salt with fine to coarse.

Notes:

The machine may stuck during using, please adjust the top black adjuster with anti-clockwise direction.

Or change your batteries (Alkaline battery recommended)



