

**360°
Revolve**



**"SHOVEL"
UP & DOWN**



LIGHT

LEVOROTATION



DEXTROROTATION


FORWARD



BACKWARD



● WITH RECHARGEABLE BATTERIES AND CHARGER




CHARGE AND INSTALLATION OF RECHARGEABLE BATTERIES:

1. Open the lid and take out rechargeable batteries. Charge the batteries as showed in picture.
2. Install charged batteries into car as showed in picture. Then put back the lid.


BATTERY WARNING:

1. Non-rechargeable batteries are not to be recharged.
2. Rechargeable batteries are to be removed from the toy before being charged (if removable).
3. Rechargeable batteries are only to be charged under adult supervision (if removable).
4. Different types of batteries or new and used batteries are not to be mixed.
5. Only batteries of the same or equivalent type as recommended are to be used.
6. Batteries are to be inserted with the correct polarity.
7. Exhausted batteries are to be removed from the toy.
8. The supply terminals are not to be short-circuited.



Open the battery cover with a screw-driver

Uses 3 "AA" Size Batteries. (not included)



MADE IN CHINA



WARNING:
CHOKING HAZARD- Small parts.
Not for children under 3 years.

PRECAUCIONES:
PELIGRO DE AHOGARSE. Contiene partes pequeñas. No recomendado para niños menores de 3 años.

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS
غير مناسب للأطفال تحت سن 3 سنوات
احتياطات: خطر الاختناق. يحتوي على أجزاء صغيرة. لا يُنصح للأطفال الذين تقل أعمارهم عن 3 سنوات.
COUNTRY OF ORIGIN: CHINA
مصدر: الصين



※ SPECIFICATIONS COLORS AND CONTENTS MAY VARY FROM ILLUSTRATION