


联想tinkplus-X3 pro 产品说明书

2022-01-04-联想tinkplus-X3 pro


产品说明书 尺寸: 73x93mm 材质: 80g铜版纸 (折页)

联想thinkplus Bone conduction Headphone X3 pro
骨传导蓝牙耳机



使用说明书
使用前请阅读使用说明书

物品清单



产品规格

蓝牙版本: V5.3
有效距离: ≥10m
电池容量: 135mAh
额定输入: 5V 100mA
充电时间: 约2小时
播放时间: 约7小时
喇叭规格: 0.5W, 8Ω, 86+/-3dB
频率响应: ISM band (2.402-2.480GHZ)

(所有技术信息以实际性能为准)

产品使用简介


(1) 除说明书有特殊标示的操作方式以外, 请勿尝试拆卸或更换产品内的任何零件。
(2) 如果有任何液体不小心进入产品内时, 请立即断开连接并移开此产品。
(3) 为避免触电, 请在安装或卸载产品时, 确保手上没有沾水。
(4) 请勿将此产品放置于热源附近或直接暴露于火源附近。
(5) 请勿将本产品放置在有强大电磁力的环境中, 否则会导致产品故障。

产品操作说明

1. 开关机
长按功能键3秒, 红蓝灯闪烁开机; 长按功能键3秒, 关机灯灭。

2. 蓝牙连接
耳机开机后, 打开手机, 找到手机中的设置, 开启蓝牙 (如图示)。蓝牙搜索显示 联想tinkplus-X3 pro, 点击连接后指示灯蓝灯慢闪, 正常播放蓝灯熄灭。

产品示意图



① 开关键 ② 加号键 ③ 减号键 ④ 麦克风
⑤ 指示灯 ⑥ 骨传导震子 ⑦ 电池 ⑧ USB充电口

指示灯说明

红蓝交替;	配对状态
蓝色慢闪;	连接成功等待播放状态
蓝灯呼吸;	进入低延时游戏模式
红灯常亮;	正在充电
蓝灯常亮;	电池充满

充电指示

正常连接, 手机会显示耳机电量, 如低电报警, 即表示需要充电, 请使用标注5V 充电器连接充电线即可充电。

5V充电头 USB

功能操作

- 开机/关机: 长按 ③ 键3S
- 游戏模式: 三击 ④ 键
- ⏮ 下一曲: 双击 ④ 键
- ⏪ 上一曲: 双击 ④ 键
- 🔊 增加音量: 单击 ④ 键
- 🔇 减少音量: 单击 ④ 键
- 🗣️ 激活SIRI: 长按 ④ 键1S
- 📞 接听/挂断: 单击 ④ 键

注意事项

使用过程中请将USB硅胶塞上, 避免雨水汗液进入。如有汗水等依附在硅胶塞上, 请及时擦拭干净再打开硅胶塞进行充电。

产品中有有害物质名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制
○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB 26572规定的限量要求。
表中标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。

本表格依据SJ/T 11364的规定编制
印刷电路板组件*: 包括印刷电路板及其零部件, 电子元器件等, 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件

在中华人民共和国境内销售的电子电气产品必须标识此标志, 标志内的数字代表在正常的使用状态下的产品的环保使用期限。

保修声明

免责声明:
本使用手册没有任何形式的担保、立场表达或其他暗示, 本使用手册所提到的产品、规格及信息仅供参考, 内容亦会随时更新于网页, 恕不另行通知。

保修声明:
就本文件附随的产品做如下保证: 如产品在您购买日起十二 (12) 个月 (“保修期”) 内, 在正常使用情况下因质量瑕疵发生损坏, 能修理的, 免费修理; 经厂家确认无法修理的, 免费更换; 修理或更换后的产品, 在剩余保修期 (最短不少于 30 天) 内继续享有保修。购买日以销售发票日期为准; 如无法确定购买日, 则保修期自产品生产日期起按十三 (13) 个月计算。

如申请保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需要提供准确、完整和清晰填写的有效销售发票。

以上保证不适用于下列情况:

- 超过三包有效期的;
- 涂改保修卡、产品编码与产品本体不符;
- 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
- 因不可抗力 (如地震、战争、火灾等) 或意外导致的故障或损坏;
- 拉链、搭扣因受力过大而损坏;
- 因承载过重造成的脱线或撕裂;
- 任何因尖锐物体造成的损坏;
- 有烧痕或水浸迹象的产品;
- 因擅自拆改造成的损坏;
- 产品正常使用过程中发生的老化、褪色、磨损、破裂和其他损耗。

11. 如产品原有标识标签被更改或损毁, 本保证将失效。产品及随附物料的齐备和外观完好不属于保证范围, 您应在接收产品时当场检验并对任何不符提出异议。


以上保证是我们就产品做出的全部保证, 且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权益。

售后邮箱: frank@szeyan.cn
服务电话: 400-812-0102

“Lenovo”、“thinkplus”及其他联想标识是联想集团所属企业的商标。(本材料)提及的其他商标、公司名称、产品或服务名称可能是联想集团所属企业或其他公司的商标。
版权所有 © 2022 联想(北京)有限公司保留所有权利。




thinkplus Bone conduction Headphone X3 pro



USER MANUAL
Please read this manual carefully before using the headphones.

LIST OF ITEMS



Product specification

BT version : V5.3
Transmission distance: >10M
Battery capacity : 135mAh
Rated input : 5V 100mA
Charging time : about 2 hours
Playing time : about 7 hours
Horn specification : 0.5W, 8Ω, 86+/-3dB
Working frequency band : ISM band (2.402-2.480GHZ)

PRODUCT INTRODUCTION


(1) Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the headphone.
(2) If any liquid accidentally enters the product, disconnect and separate the product immediately.
(3) To avoid electric shock, please make sure that there is no water on your hands when installing or uninstalling the headphone.
(4) Do not place the headphone near a heat source or directly expose them to a fire source.
(5) Do not place the headphone in an environment with strong electromagnetism, otherwise they will malfunction.

PRODUCT OPERATION INSTRUCTIONS

1. Switching on and off
Press and hold the function key for 3 seconds, the red and blue lights flash on; press and hold the function key for 3 seconds, the shutdown light goes off.

2. BT connection
After the headset is turned on, open your phone, find the settings in your phone and turn on BT (as shown in the picture). BT search shows Lenovo tinkplus-X3 pro, click to connect successfully, the indicator light flashes slowly, the blue light goes off after normal playback.

PRODUCT DIAGRAM



① On/Off key ② Plus key ③ Minus key ④ Battery
⑤ Indicator light ⑥ Bone conduction oscillator ⑦ Microphone
⑧ USB charging port

INDICATOR LIGHT DESCRIPTION

Alternating red and blue	Pairing Status
Blue slow flash	Connection succeeded
Blue light breathing	Enter low latency game mode
Red light is always on	Being charged
Blue light is always on	Battery full

CHARGING INDICATION

Normal connection, the phone will show the headset power, such as low battery alarm, that is, the need to charge, please use the labeled 5V charger connected to the charging cable can be charged.

5V Charging head Micro USB

FUNCTION OPERATION

- Turn on and off: Click on the ③ keys 3S
- Game Mode: Triple strike ④ keys
- ⏮ Next song: Double click ④ keys
- ⏪ Previous song: Double click ④ keys
- 🔊 Increase the volume: Click on the ④ keys
- 🔇 Reduce the volume: Click on the ④ keys
- 🗣️ Activate SIRI: Long press ④ keys 1S
- 📞 Answer and hang up: Click on the ④ keys

CAUTIONS

Please plug the USB silicone plug during use to avoid the entry of rain and sweat. If there is sweat and other adhering to the silicone plug, please wipe clean in time before opening the silicone plug for charging.

NAME AND CONTENT OF HAZARDOUS PRODUCTS SUBSTANCES IN

Part Name	Harmful materials					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
○ : Indicates that the content of the hazardous substance in all homogeneous materials of the part is in Below the limit requirements specified in GB/T 26572.
× : Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirements specified in GB/T 26572.
The parts marked with “X” on the form cannot be replaced by hazardous substances due to restrictions on the global technological development level.

Printed circuit board components*: including printed circuit boards and their parts, electronic components, etc., Depending on the product model, the product you purchased may not contain all the above components

Electronic and electrical products sold in the People's Republic of China must mark this Logo, the number in the logo represents the product under normal use environmental protection use period.

WARRANTY STATEMENT

Disclaimer
This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the webpage at any time, without additional line notification.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase (“Warranty Period”), under normal conditions of use due to quality defects damaged, can be repaired free; if the manufacturer confirms that it cannot be repaired, free replacement; repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchase date by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 Months calculation. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. The validity period of the three packs is exceeded;
2. Alteration of the warranty card and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage/impairment or damaged;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident bad;
5. The zipper and buckle are damaged due to excessive force;

6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses occurred during normal use of the product.
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.
After-sales service Email: frank@szeyan.cn
Service supervision hotline: 400-812-0102

“Lenovo”、“thinkplus” and other Lenovo logos are Lenovo Group The trademark of the affiliated company. (This material) mentioned other trademarks, company names, products or services.
The name may be a trademark of a Lenovo Group company or another company.
Copyright © 2022 Lenovo (Beijing) Co., Ltd. All rights reserved.

