

SIZE:60x90MM

正

Wireless Car FM Transmitter User Manual



To avoid interference by local radio signal:
(1)Adjust the FM transmitting frequency to match the car radio's FM channel, long press [▲▼] button to enter into the FM mode, and when the frequency display on the LED display you can adjust the frequency through rotate the front-left and right will automatically exit FM mode when idle for 3 seconds.
(2)Turn on the wireless car radio and keep "TUNE" in your phone's interface, but it should be connected.

5.2 Interference detection function:
This product is equipped with a battery voltage detection function. Any shorting press [▲▼] Frequency detection long press [▲▼] to display "battery voltage".
1.Fm 12V car, when the voltage is under 11.8V or higher than 14.8V, it means a car battery issue.
2.Fm 24V car, when the voltage is under 23.8V or higher than 27.8V, it means a car battery issue.

5.3 Wireless connection:
For the first time use you must manually connect the wireless on your mobile phone. Turn on your smart phone "Wlan", search the FM with the device name "FM".
2. After connected, there is a prompt "yes". Wireless connected successfully.

5.4 Play Mobile Music:
After the wireless connection, you can play the music of your mobile phone, by wireless transmission to the car speakers. You can use the phone to operate the music. You can also control the music through the device. Press the [▲▼] key to pause/stop, and press [▲▼] / [▲▼] keys to choose the previous song / next song.

5.5 Adjust the Volume:
When playing a song, rotate the [▲▼] key clockwise to

Thank you for choosing this Wireless Car FM Transmitter please read the user manual carefully so that you can quickly understand the function and operation of this product.

1. Product Introduction

This device can use it to play music or answer a phone call through both wireless connection and the same FM radio signal.
You can also insert the TF card or U disk into the device to play music via FM radio signal.
After you plug the wireless FM transmitter into car's cigarette lighter receptacle, it will display the voltage.

2. Product Features

1. Wireless FM, Support voice/calling prompt
2. Support charge of Andriod/iphone or other devices via USB
3. Built-in LED frequency display/car battery voltage display
4. Support to read U-disk and TF Card (up to 32GB), support folder switch function
5. Wireless searching/U-disk repeat/repeat/next/other functions
6. Noise cancellation and noise suppression/CS technology
storing 2-18
7. Automatic power-off memory function
8. Wireless stereo/AUX music play

3. Package contents

1*FM transmitter*1 User Guide*1

4. Product appearance



5. Operation Instructions

5.1 First time to use this device:
(1)Plug the FMF into the car cigarette lighter hole to power on,
(2)Then car battery voltage display function starts working, the display will show "car battery voltage normal (reference)".
(3)Then FMF self-diagnose "BT", with a voice "wireless is ready to pair", and display self-pair from BT to frequency alternately until you connect with Bluetooth or insert USB/TF card.
(4)To use FMF music playing function, turn on the car FM radio, choose a clear channel. Make sure the car radio channel is clear.

6. Technical Parameters

Weight: 25g Screen: LED display
Data Interface: USB2.0 Power supply: DC12-24V
USB output: 2.1A max Launch distance: <5 meters
Support: TF card/SD card capacity: up to 32GB
Support file type: MP3/WMA/WAV/FLAC/APE
FM frequency range: 87.5-108MHz (100KHz stepping)
Working temperature: -10~60°C

7. Usage of Notes:

(1)For the best audio quality, please turn up the volume of your phone (the max level), then turn down the volume of your car radio to around 25.
(2)For Noise: If the audio has too much noise, please select another radio frequency, the chosen frequency may be occupied by a radio station or have too much interference.
(3)The USB charging port of this product is only used for charging. Do not use high-power equipment or power inverter to avoid damage.
(4)Please use the voltage specified by this unit (DC 12/24V), otherwise the machine may work abnormally or be damaged.
(5)For Unstable Connection: Please firstly try with another phone or tablet; if that doesn't work, you can contact us.
(6)To prevent your car battery from being drained, please be sure to remove the device from the car cigarette lighter after use.