FR-Mode d'emploi GUIRLANDE AMPOULE TRANSPARENTE EXTERIEURE 4M50 LA10423

IMPORTANT, A CONSERVER POUR CONSULTATION ULTERIEURE : A LIRE

Afin de garantir une installation et une utilisation sûres et adéquates, ainsi qu'un bon fonctionnement du produit, suivez toujours attentivement ces instructions et conservez-les pour un usage ultérieur

Consignes de sécurité :

- Ne pas brancher la guirlande sur son alimentation lorsqu'elle est dans son emballage
- Les lampes ne sont pas remplaçables. La source lumineuse de ce luminaire n'est pas remplaçable; lorsque la source lumineuse atteint sa fin de vie, le luminaire entier doit être remplacé.
- remplace. Si des lampes sont cassées ou endommagées, ne pas utiliser la guirlande ni la mettre sous
- Si des tampes sont cassese ou endominiages, ne pas diniser la guinande ni la mettre sous tension, mais éliminer dans le respect de l'environnement. Le câble extérieur souple de cette guirlande ne peut être remplacé. S'il est endommagé, la guirlande doit être éliminée dans le respect de l'environnement. ATTENTION CETTE GUIRLANDE LUMINEUSE NE DOIT PAS ÊTRE UTILISÉE SANS QUE TOUS LES JOINTS D'ÉTANCHÉITÉ NE SOIENT EN PLACE.
- Guifande lumineuse non prévue pour être interconnectée. Ne pas interconnecter cette guifande lumineuse avec une autre guifande lumineuse.

 Utiliser cette guifande avec le transformateur fourni.

Présentation du produit :



Caractéristiques générales :

- Longueur totale : Longueur avec lampes LED : Espace entre 2 LED : Nombre de LED :

- Lampes LED non remplaçables Diamètre des boules : Alimentation : 220-240V~, 50/60 Hz
- Alimentation guirlande : 3.2V = . 300 mA, 0.96W
- Usage intérieur et extérieur

Montage et utilisation :

EN-Instructions for use EXTERIOR FESTOON LIGHTS WITH TRANSPARENT BULBS 4M50 LA10423

IMPORTANT - RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

In order to ensure safe and adequate installation and use, as well as correct functioning of the product, be sure to follow these instructions carefully and keep them for future use.

Safety instructions:

- Do not plug the festoon lights into the power source when they are still inside packaging. The lamps cannot be replaced. The light source for this lamp is not replaceable; when the light source no longer works, the whole lamp must be replaced. If the lamps are broken or damaged, do not use the festoon or switch it on, but dispose of it in an environmentally-friendly way. The flexible exterior cable on these festoon lights cannot be replaced. If it is damaged, the festoon must be disposed of in an environmentally-friendly way. ATTENTION THIS FESTOON LIGHT GARLAND MUST NOT BE USED WITHOUT ALL THE WATERTIGHT CONNECTORS BEING IN PLACE. Festoon lights not intended to be connected to others. Do not connect this festoon light garland to another set of festoon lights. Use this festoon garland with the transformer supplied.

Product presentation:

1 set of festoon lights



General details:

- Total length: Length with LED lights:

- Lengin Wint Leb nglis.
 Space between 2 LEDs:
 Number of LED lights:
 Non-replaceable LED lights
 Bulb diameter:
 Power supply: 220-240V~, 50/60 Hz
 Festoon light power: 3 2V, 300 mA, 0.96W
 Indoor / outdoor use

Mounting and use:




Raccorder la prise de la guirlande au transformateur. Visser correctement la prise sur le pas de vis du transformateur, Installer la guirlande à l'aide des crochets situés sur chaque boule à l'endroit désiré. Raccorder le transformateur à une prise adéquate.

Pour une utilisation dans des zones partiellement protégées de la pluie. Protégé contre les projections d'eau, Protégé contre les corps solides supérieurs à 1 mm.



Ce produit est un déchet d'équipement électrique et électronique dangereux pour l'environnement et la santé humaine. Il ne doit pas être jeté avec vos déchets ménagers. Renseignez-vous auprès des autorités locales concernant le système de recyclage en vigueur.



Edité par Groupe CMP 157, avenue Charles Floquet – Bât. 4C/4D 93150 Le Blanc-Mesnil – France www.cmp-paris.com Fabriqué en Chine





Connect the festoon plug to the transformer. Screw the plug into the transformer screw thread correctly. Install the festoon lights using the hooks located on each bulb in the desired location. Connect the transformer to a suitable outlet.

For use in areas that are partly sheltered from rain.

Protect from splashes of water, protect from solid objects bigger than 1 mm.

Disposal:



This product constitutes electrical and electronic equipment waste, which is harmful to the environment and to human health. It must not be disposed of with your household rubbish. Find out from your local authorities about the availability of recycling.

CE	Complies with requirements stated by the community regulator
	Class II equipment
	Class III equipment
~	Alternating current (AC)
===	Direct current (DC)
IP44	Protect from solid objects with a diameter ≥ 1.0 mm Protect from splashes of water

Published by

Groupe CMP 157, avenue Charles Floquet – Bât. 4C/4D 93150 Le Blanc-Mesnil – France www.cmp-paris.com

Made in China

