

Download SmartCONTROL app




Télécharger l'application SmartCONTROL
Laden Sie die App herunter SmartCONTROL
Descarga la aplicación SmartCONTROL
Scaricare l'applicazione SmartCONTROL

Add remote control in App




Ajouter la télécommande dans l'app
Fernbedienung in app hinzufügen
Añadir el mando en la aplicación
Aggiungere il telecomando nell' app

1




2



Select «My Controllers»
Sélectionner «Mes Contrôleurs»
Wählen Sie «Meine Controller»
Seleccionar «Mis Controladores»
Selezionare «i miei Telecomandi»

3

Put remote control in «smartphone» mode
Mettre la télécommande en mode «smartphone»
Fernbedienung in «Smartphone» -Modus setzen
Poner el mando en modo «smartphone»
Impostare il telecomando in modalità «smartphone»




Add a light bulb in app




Ajouter une ampoule dans l'app
Fügen Sie eine Glühbirne in der App hinzu
Añadir una bombilla en aplicación
Aggiungere una lampadina nell' App

1



2

Follow the wizard
Suivre l'assistant
Folgen Sie dem Assistenten
Seguir el menú
Seguire la procedura guidata



AwoX SmartControl



Compatibility

Compatibilité
Kompatibilität
Compatibilidad
Compatibilità




Eglo LED Connect
AwoX SmartLIGHT Mesh

For more information, read the user guide

Pour plus d'information, lire le mode d'emploi
Weitere Informationen finden Sie in der Bedienungsanleitung
Para más información, leer la guía del usuario
Per ulteriori informazioni, leggere il manuale d'uso


<http://www.awox.com/user-guides>



Mesh Remote Control & Light Bulb
Télécommande Mesh & Bombilla
Mesh Fernbedienung & Glühbirne
Mando de control Mesh & Bombilla
Telecomando Mesh & Lampadina




1





3

3 seconds long press

Appui long de 3 secondes
Für 3 Sekunden drücken
Presión larga de 3 segundos
Premere a lungo 3 secondi




2




No blink. Redo step
Pas de clignotement. Refaire
Kein Blinzeln. Wiederholen
Sin parpadeo. Volver al
Ripeti il passaggio

Blink
Clignotement
Blinkend
Luz intermitente
Lampeggiante




Select a Color

Sélectionner une couleur
Wählen Sie eine Farbe
Selecione un color
Selezionare un colore



Record as a favorite


Enregistrer comme favori
Als Favorit festlegen
Guardar como favorito
Registra come preferito



3 seconds long press
Appui long de 3 secondes
Für 3 Sekunden drücken
Presión larga de 3 segundos
Premere a lungo 3 secondi

Select an Intermediate Color

Sélectionner une couleur intermédiaire
Wählen Sie eine Übergangsfarbe
Selecione un color intermedio
Selezionare un colore intermedio



A

B

Multiple click
Appui successif
Mehrmals klicken
Presiones sucesivas
Stampa multipla