

# TECHNICAL DATA

<b>CE</b> 312	<b>KEMPER</b>		<b>Outdoor stove</b>				<b>PIN 1312BR4806</b>			
<b>Gas category</b>	<b>I<sub>3+</sub> (28-30/37)</b>									
<b>Gas type</b>	<b>Butane</b>					<b>Propane</b>				
<b>Use pressure</b>	<b>28-30 mbar</b>					<b>37 mbar</b>				
<b>Item code</b>	<b>104980</b>	<b>104981</b>		<b>104982</b>			<b>104983</b>			
<b>Number of burners</b>	<b>1</b>	<b>2</b>		<b>3</b>			<b>4</b>			
<b>Type of burner</b>	<b>Medium</b>	<b>Medium</b>	<b>Large</b>	<b>Small</b>	<b>Medium</b>	<b>Large</b>	<b>Small</b>	<b>Medium</b>	<b>Medium</b>	<b>Large</b>
<b>Dimension of injectors (mm)</b>	<b>0.53</b>	<b>0.53</b>	<b>0.59</b>	<b>0.47</b>	<b>0.53</b>	<b>0.59</b>	<b>0.47</b>	<b>0.53</b>	<b>0.53</b>	<b>0.59</b>
<b>Consumption (g/h)</b>	<b>88</b>	<b>88</b>	<b>102</b>	<b>62</b>	<b>88</b>	<b>102</b>	<b>62</b>	<b>88</b>	<b>88</b>	<b>102</b>
<b>Rated capacity (kW)</b>	<b>1.2</b>	<b>1.2</b>	<b>1.4</b>	<b>0.85</b>	<b>1.2</b>	<b>1.4</b>	<b>0.85</b>	<b>1.2</b>	<b>1.2</b>	<b>1.4</b>



## SAFETY WARNINGS

1. Only use this appliance outdoor or possibly in properly-aerated premises, at safety distance from any heat source, flame or spark and away from accumulated dirt or flammable material.
2. Place the stove on ground or floor, anyway always horizontally. Never place the stove on surfaces made of wood, plastic or other flammable materials.
3. Any change to the appliance can be dangerous. Never modify your stove and do not absolutely disassemble the appliance and its components. Only qualified and specialized personnel must repair the appliance.
4. Parts, which have been sealed by the manufacturer, should not be altered by the user.
5. Check no damage has occurred to the appliance. Do not operate the appliance if damaged.
6. Only use this stove for food cooking.
7. Never use the appliance with damaged or worn seals.
8. Never use the appliance if leaking, damaged or badly operating.