

ITM. /ART. 1005855

DURACELL®

RECHARGEABLE POWERBANK



USER MANUAL

POWERBANK PB3: 10050 mAh

FOR MOST SMART PHONES, TABLETS AND MOST
USB-POWERED DEVICES

INSTRUCTIONS:

1.



Charging your PowerBank

2.



Charging your device

3.



Power/Battery indicator

INCLUDED IN THE PACKAGE

- PowerBank PB3: 10050 mAh/36.5Wh Rechargeable Lithium Ion Battery, Output=5V/2.4A shared
- Micro USB to USB charging cable
- User manual

COMPATIBILITY

Duracell PowerBank is compatible with most Smart Phones, tablets and most USB powered devices.

SAFETY & SUPPORT

IMPORTANT SAFETY INSTRUCTIONS

WARNING - When using this product, basic precautions should always be followed:

- a) Read all the instructions before using the product.
- b) To reduce the risk of injury, close supervision is necessary when the product is used near children.
- c) Do not expose PowerBank to rain or snow.
- d) Use of a faulty charger to charge this PowerBank may result in a risk of fire or injury to persons.

- e) Do not use the PowerBank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
- f) Do not use the PowerBank if it is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- g) Do not disassemble the PowerBank.
- h) Do not expose the PowerBank to fire or excessive temperature. Exposure to fire or temperature above 60°C may cause explosion.
- i) This PowerBank has no serviceable parts. Call DURACELL if you experience any problems.
- j) Do not operate where aerosol (spray) products are being used or where oxygen is being administered
- k) Only set or store on clean dry surfaces. Do not place on surface that is wet from water or cleaning solvents.
- l) Do not operate in a closed environment, such as a pocket, backpack or carry case

SAVE THESE INSTRUCTIONS

3 YEAR LIMITED WARRANTY

Subject to applicable law, Duracell International Operations, sell its Duracell Mobile products (hereinafter "Product(s)") with the intent that they are free of defects in manufacture and workmanship for three years from the date of original purchase, except as noted below. Duracell warrants that its Products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

Duracell does not authorize anyone, including, but not limited to, retailers, the subsequent consumer purchaser of the product from a retailer or remote purchasers, to obligate Duracell in any way beyond the terms set forth herein. This warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped Product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use; or any other conditions whatsoever that are beyond the control of Duracell.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. DURACELL SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPLACEMENT OF ANY PART OR PARTS WHICH ARE

FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY. REFUNDS WILL BE GIVEN IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, DURACELL RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPAIR OR REPLACEMENT.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such Products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any Products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of Duracell. This warranty provides you with specific legal rights. You may have additional rights which may vary from country to country. Because of individual regulations, some of the above limitations and exclusions may not apply to you.

For more information regarding our Product line and customer Service web contact, please visit:



For service or repair - do not return this unit to the retailer. Contact Duracell Consumer Relations.

BATTERY SAFETY INFORMATION

- Do not dismantle, open or shred the battery.
- Do not expose the battery to heat or fire.
- Avoid storage in direct sunlight.
- Do not short-circuit the battery.
- Do not subject the battery to mechanical shock.
- Keep the battery out of the reach of children.
- Keep the battery clean and dry.
- Do not leave a battery on prolonged charge when not in use.

BATTERY STORAGE

- Store in a cool dry place.
- Store charged at regular ambient temperatures, 25°C ± 5°C.

BATTERY CAUTION

The lithium rechargeable battery used in this charging device may present a risk of fire or chemical burn if mistreated. Do not disassemble, short circuit, crush, expose to heat above 60°C or incinerate. Do not operate outside of its operating temperature range of 0°C to 40°C. Misusing or incorrectly connecting the charging device may cause electric shock to users and damage equipment. Read instructions carefully. The PowerBank may become warm and may reach 50°C under extended high-power operation. During operation,

keep the charging device away from materials that may be affected by these temperatures. Follow manufacturer instructions.

CORRECT DISPOSAL FOR THIS CHARGING DEVICE

Please follow any local requirements to recycle this lithium rechargeable device. This marking indicates that this product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



Devices sold separately.

 **(UK)** 0800 716434 **(IRL)** 1 800 509 176
(DE) 0800 101 2112 **(AT)** 0800 1025 1956
(CH) 0800 000 885 **(BE)** 0800 509 95
(NL) 0800 265 8616 **(IT)** 800 125 662
(ES) 900 800 522 **(PT)** 800 781 012
(GR) 210 66 75 000 **(DK)** 78734857
(SE) 8525038571 **(FI)** 942705057
(NO) 6379195 **(ZA)** 00800 77628282
(TR) 0 850 502 61 40 **(IL)** 1-800-225-510
(FR)

0 800 946 790

**Service & appel
gratuits**

©2017 Duracell.

Made in China for Duracell Batteries BVBA.

Nijverheidslaan 7, 3200 Aarschot, Belgium.

Duracell International Operations Sàrl.

Rue du Pré-de-la-Bichette 1, CH-1202, Geneva, Switzerland.

DURACELL®
RECHARGEABLE POWERBANK