




© Guangdong Xin Yu Technology Industrial Co., Ltd
 Add: Laimel Industrial District, Chenghai,
 Shantou City, Guangdong Province, China
 Tel: +86-754-8551-3333 Fax: +86-754-8551-1888
 Website: www.xq-toys.com

YARI: BOĞULMA TEHLİKESİ -
 Küçük parçalar 3 yaş altındaki
 çocuklara uygun değildir

NOT INCLUDED
 Vehicle:
 5 X AA batteries
NOT INCLUDED
 Transmitter:
 2x AA Batteries

Contents:
 1x vehicle,
 1x controller.

Manufactured / Imported by:
 Spectron BV
 Solingenstraat 53
 7421 ZR Deventer
 The Netherlands
 Support Helpdesk:
 Item nr.: XQRC12-2AA
 Batchcode: XQR1708
 info@spectrontoys.com



Made in China

Ferrari
 Official Licensed Product
 Produced under license of Ferrari S.p.A. The name
 FERRARI, the PRANCING HORSE device, all associated
 logos and distinctive designs are property of Ferrari S.p.A.
 The body designs of the Ferrari cars are protected as Ferrari
 S.p.A. property under design, trademark and
 trade dress regulations



XQRC12-2AA
 ITEM NO. 3623
 4 895181 836236

BATTERY CAUTIONS:

1. Don't mix old and new batteries. Always replace all batteries at the same time.
 2. Don't mix batteries of different types. (Alkaline, standard batteries or rechargeable batteries).
 3. Insert the "AA" batteries with their polarity (+/-) as shown inside the battery compartment.
 4. The supply terminals are not to be short-circuited.
 5. Don't recharge non-rechargeable batteries. Rechargeable batteries may only be charged under the supervision of an adult.
 6. Remove all batteries if vehicle will not be used for a long period of time.
 7. Dispose of batteries safely. Don't dispose of batteries in fire as they may explode.
- Keep these instructions for future reference: they contain important information.

INSTRUCTION:

1. Install five "AA" batteries inside the battery compartment that is underneath the chassis, taking care to observe the polarity. Fit back the cover.
2. Insert 2x AA batteries inside the controller. The car is now ready to run.
3. Turn the two switches located on both the car and the controller to the "ON" position and then operate the car.
4. If the car does not run in a straight line adjust the steering alignment lever located beneath the chassis.
5. When the light in the controller begins to dim, it may be time to replace the AA batteries.
6. When your R/C model car begins to lose performance, power or function, it may be time to replace the five "AA" batteries.

