



User Manual

	Getting Started 01 <ul style="list-style-type: none"> 1. Power On/ Off: <ul style="list-style-type: none"> Press the Locator Function Button once to turn it on. It should a ringing chime to indicate that it is powered on. To power off, hold the same button for at least three seconds. You will hear two beeps to indicate that your Locator is powered off. 2. Check For Updates: <ul style="list-style-type: none"> To use the Apple® Find My® app to locate Locator, the latest version of iOS®, iPad OS, or mac OS is recommended. The Find Items app on Apple Watch® requires the latest version of watch OS®. 	Add Your“Locator” 02 <ul style="list-style-type: none"> 1. Start the App <ul style="list-style-type: none"> Open Find My app on your supported iPhone® or iPad® Allow notifications from the app 2. Connect your Locator <ul style="list-style-type: none"> Power on your Locator Tap "+" then "Add Other Item" Once your Locator is located (AIYATO-B1), tap "Connect" Choose a recognizable name and emoji for your Item Locator and tap "Continue" - Find My will ask for confirmation to add your Locator to your Apple ID - tap "Continue" Tap "Finish" and your Locator will be set up and ready to be connected to whatever item you wish to locate, e.g., your keys 	Locate Your Item 03 <ul style="list-style-type: none"> 1. Find Locator when it is Nearby <ul style="list-style-type: none"> Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch Tap on your Locator from the list Tap "Play Sound" to make your Locator beep Tap "Stop Sound" to stop the beeps once you find your item 2. Find Locator's Last Known Location <ul style="list-style-type: none"> Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch Tap on your Locator from the list Your item Locator's last known location will appear on the map To navigate to that last known location, tap "Directions" to open the Maps app 	Find Item When Out of Range 04 <ul style="list-style-type: none"> 1. Enabling "Notify When Left Behind" <ul style="list-style-type: none"> Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch Tap on your Locator from the list Under "Notifications", enable the "Notify When Left Behind" toggle You will receive a notification when you leave your Locator behind and it's no longer in range of your device. 2. Enabling "Notify When Found" <ul style="list-style-type: none"> Under "Notifications", enable the "Notify When Found" toggle When your Locator is seen by another Find My enable d device, you will receive a notification of its updated location Note: "Notify When Found" can only be activated when your Locator is out of range 	When Your Item is Lost 05 <ul style="list-style-type: none"> 1. Enabling "lost Mode" <ul style="list-style-type: none"> Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch Tap on your Locator from the list Under "Lost Mode", tap "Enable" A screen detailing Lost Mode will pop up, tap "Continue" Enter your phone number or email address and tap "Next" You may enter a message that will be shared with the person that finds your item Tap "Activate" to enable "Lost Mode" Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled Note: When "Lost Mode" is enabled, your Locator is locked and cannot be paired to a new device 	Resetting Your Locator 06 <ul style="list-style-type: none"> 1. Remove the Locator from Find My™ app <ul style="list-style-type: none"> Open Find My app and select the "Items" tab Tap on your Locator from the list Please ensure "Lost Mode" is disabled Scroll to the bottom of the screen and tap "Remove Item" A summary will open, tap "Remove" to confirm 2. Factory Reset Your Locator: <ul style="list-style-type: none"> After successfully removing the Locator from Find My™ app, press the Locator's function button four times rapidly and then hold it a fifth time until you hear a ringing chime. The Locator is now reset and ready to be paired to a new Apple ID. 														
Locator Product Specification 07 <table border="1" data-bbox="147 627 634 851"> <tr> <td>1. PPID No</td> <td>725550-420539</td> </tr> <tr> <td>2. Product Size</td> <td>47 x 28.5 x 6.0 mm /1.85 x 1.12 x 0.23 inch</td> </tr> <tr> <td>3. Product Weight</td> <td>8 g / 0.282 oz</td> </tr> <tr> <td>4. Battery</td> <td>Built in battery</td> </tr> <tr> <td>5. Voltage</td> <td>DC 3V</td> </tr> <tr> <td>6. Current</td> <td>≤5uA(Standby) / ≤10mA(Max)</td> </tr> <tr> <td>7. Color Box Size</td> <td>50mm x 18.5mm x 84mm</td> </tr> </table>	1. PPID No	725550-420539	2. Product Size	47 x 28.5 x 6.0 mm /1.85 x 1.12 x 0.23 inch	3. Product Weight	8 g / 0.282 oz	4. Battery	Built in battery	5. Voltage	DC 3V	6. Current	≤5uA(Standby) / ≤10mA(Max)	7. Color Box Size	50mm x 18.5mm x 84mm	08 <ul style="list-style-type: none"> 1. Replace the Battery: <ul style="list-style-type: none"> Use your fingerails at the small gap on the side of your Locator to carefully open the case Replace the battery with a new CR2032 battery placing it positive side up (text facing up) Carefully align the top hole on both sides to close 2. Unwanted Tracking Detection: <ul style="list-style-type: none"> If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways: <ol style="list-style-type: none"> If you have an iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS, iPod touch, or iPad OS 14.5 or later. If you don't have an iOS device or smartphone, the owner's locator will automatically make a sound after a period of time. These features were created specifically to discourage people with its owner for a period of time will emit a from trying to track you without your knowledge. 	09 Q&A <ul style="list-style-type: none"> 1.What is the distance it reaches? A.You can locate your things globally through our tag. Only when you approaching your item, you can make item play sound, about within 10m. 2.Why does tracker not separately track the devices. When I track an item, the Find app is showing all items in the same location and they are not? A.Make sure that all the find my device are in different position, at least 262 feet far away. If the distances within our devices are within 262 feet(80m), then all of them will show at the same location on Find My app. 3.Can phone be found from tag? A. No. Support find my device be found from iPhone. Like Apple airtags do. 	10 Q&A <ul style="list-style-type: none"> 4.Is it compatible with Google pixel? A.NO. I'm pretty sure it says in the product description that this is only compatible with iOS- iPhone, iPad... 5.Is the battery user-replaceable? What is the battery life? What is the range? What features of the airtag does it lack? The battery is user-replaceable which has 8 month to 1 year life, and it has all the functions that airtag dose but the directionality (arrow). 6.What type of battery does this take? Button cell? Which number? Easy to replace? A.It's CR2032, which is user-replaceable 	11 Q&A <ul style="list-style-type: none"> 7.Can multiple family members track this with the Find My app? Each locator can only connect to 1 iOS device in one time, that means only 1 family member can track it with the Find My app. 8.What's the battery life and can it be charged? Normally, the battery can last up to 1 year. Sorry, it cannot be charged, but you can replace the battery when it runs out. 	12 Regulatory safety information: <p>Potential esophageal perforation, swallowing may cause serious injury or death in just 2 hours. The causes are chemical burn and potential perforation of the esophagus. If you suspect your child has swallowed or inserted a button cell, please call the 24-hour Poison Information Center immediately for quick expert advice.</p> <p>Battery warning: This device uses a CR2032 button battery. Rated voltage 3V, rated current 210-240 mAh. If the following guidelines are not followed, the lifespan of the lithium-ion battery in the device may be shortened or damaged. Do not recharge, disassemble, heat (-20 °C+70 °C), or burn it. The risk of equipment, fire, chemical burns, electrolyte leakage, and/or injury. Do not disassemble, hole or damage the device or battery. Do not expose the battery to flames, explosions, or other hazards. Do not use sharp objects to remove the battery.</p>	
1. PPID No	725550-420539																			
2. Product Size	47 x 28.5 x 6.0 mm /1.85 x 1.12 x 0.23 inch																			
3. Product Weight	8 g / 0.282 oz																			
4. Battery	Built in battery																			
5. Voltage	DC 3V																			
6. Current	≤5uA(Standby) / ≤10mA(Max)																			
7. Color Box Size	50mm x 18.5mm x 84mm																			