






## TRUE WIRELESS SOUND EARPHONES 2G MANUAL



### CONTENTS



### PRODUCT OVERVIEW



- 1. LED indicator
- 2. Type-C Charging port
- 3. MFB (Multi-Function Button)
- 4. Microphone

### PRODUCT SPECIFICATION

Bluetooth version: V5.3  
 Frequency Response: 20-20000 Hz  
 Play time: 6 hours  
 Standby time: 160 days  
 Transmission distance: 10 m  
 Charging case battery: 320 mAh  
 Earphones battery capacity: 40 mAh  
 Charging time: 1.5 hour  
 Charging voltage: DC 5V


### FIRST TIME USE/PAIR TO NEW DEVICE

Take both earphones out from the charging case to activate the earphones.  
 Note: please charge your earphones before first time use (see "Charging Earphones" and "Charging Case" for details).



### PAIR WITH BLUETOOTH DEVICES


The Bluetooth device should automatically start searching for the new play device (some may require you to select "search for/add new device")



1. Turn Bluetooth function on in the settings of your Bluetooth enabled device.
2. Turn the earphones on by taking both earphones out from the charging case which will detect Bluetooth enabled devices near you to enter pairing mode.
3. "OTL TWS2" will appear on the Bluetooth device list, select "OTL TWS2" to establish pairing.

When you want to play audio from another Bluetooth device, disconnect the earphones from the original device and follow steps 1-3 to re-pair the earphones with a new Bluetooth enabled device.

### FUNCTIONS



**PLAY / PAUSE**  
 When listening to music, tapping right or left earphone MFB twice to play/pause.



**SKIP TRACK FORWARD/BACKWARD**  
 Whilst listening to music, tapping the right earphone MFB for 3 times to forward to the next track, or tapping the left earphone MFB for 3 times to go backwards to the previous track.



**REJECT CALL**  
 Hold MF button on right or left earphone for 2 seconds to reject the incoming call.



**ANSWER CALL/HANG UP CALL**  
 Tapping the right or left earphone MFB twice to answer the incoming call and tapping twice again to hang up.



**VOICE ASSISTANT**  
 Hold right or left earphone MFB for 3 seconds to activate voice assistant (i.e. Siri or Google Assistant)

### POWER-ON

Take both earphone out from the charging case and both earphone will be automatically power on (make sure the charging case is charged) or hold each earphones MFB for 5 seconds to power on.

### POWER OFF

Put both earphones back into the charging case and close the lid, it will automatically power off or hold each earphones MFB for 5 seconds to power off.  
 Note: The earphones will automatically power off if not being paired with any devices for 3 minutes.

### CHARGING THE EARPHONES

The LED indicator light (earphones) will be on solid during charging and will be off completely once it is fully charged.

### CHARGING THE CASE

Please charge your charging case before first time use. Ensure to charge via the provided type-C cable. The LED indicator light will flash during charging and will turn on solid once it is fully charged.

The earphones playtime is approximately 6 hours on a single charge. The charging case can fully recharge the earphones approximately 3 times, but when the charging pod indicates the battery is low, please charge via the included type C USB cable for 1.5 hours for a full charge.

### CHANGING EAR TIPS

To remove an ear tip, pull firmly with your fingers at the base of the ear tip. To attach the ear tip, with your fingers at the base of the ear tip, push the ear tip onto the connector until it clicks into place. For more tip sizes, see inside box.

### TROUBLESHOOT

If an error occurs with the earphones, please follow the steps below:

1. Turn the Bluetooth function off from desired device
2. Take both earphones out of the charging case (ensure both earphones power on holding MBF 3 seconds to power on)
3. Turn the Bluetooth function back on
4. Search for "OTL TWS2" from Bluetooth enable device to pair.

When the earphones power is low, the Bluetooth range may be affected. Please charge the earphones to avoid disruption during use.

Please see our website [www.otltechnologies.com](http://www.otltechnologies.com) for general troubleshooting method instructions.

### PRODUCT GUARANTEE AND SAFETY INFORMATION

#### WARRANTY:

This product is warranted against defective materials and workmanship. If the warranty service is required, you should return the product to the retailer from where it was purchased. If the item was purchased in the United Kingdom, the guarantee period is for 12 months from the date of purchase. If it was purchased in the EU, then the guarantee period is 24 months from the date of purchase.

#### WARRANTY CONDITIONS

1. This warranty is only valid if, when warranty service is required, the original invoice or sales slip is produced, and the serial number on the product has not been defaced.
2. The manufacturer's obligations are limited to the repair or, at its discretion, replacement of the product or the defective part.
3. Warranty repairs must be carried out by an authorised dealer or authorised

service centre. No reimbursement will be made for repairs carried out by non-authorised parties, and any such repair work or damage to the product caused by such repair work will not be covered by the warranty.

4. This product will not be considered to be defective in materials or workmanship by reason that it requires adaptation in order to conform with national or local technical or safety standards in force in any country other than those for which it was originally designed and manufactured. This warranty will not cover, and no reimbursement will be made for, any such adaptation, nor any damage which may result from it.
5. This warranty covers none of the following:
  - Maintenance and repair or replacement of parts due to normal wear and tear.
  - Cost relating to transport, removal or installation of the product.
  - Misuse (including the failure to use this product for its normal purpose) or incorrect installation.
  - Damage caused by lightning, water, fire, Acts of God, war, public disturbances, or other causes beyond the control of the manufacturer.
6. This warranty is valid for any person who legally acquired the product during the warranty period.
7. The consumer's statutory rights under any applicable legislation, whether against the retailer or the manufacturer, and whether arising under contract or otherwise, are not affected by this warranty.

#### SAFETY INSTRUCTIONS:

Read all the instructions carefully before using the product and keep them for future reference.

- Wearing earphones limits your ability to hear noises around you, regardless of the volume level. Use with caution and consideration.
- Do not immerse in water.
- Unsuitable for use by children under the age of 3 due to small parts which may cause choking.
- Do not use these earphones whilst operating machinery, driving, riding a motorbike or bicycle, or in situations where an inability to hear surrounding noise may present a danger to yourself or others.
- The device may become warm while charging.
- Set volume to low before turning on sound.
- Long-term exposure to loud noise may cause damage to eardrums or loss of hearing.

#### WARNING

- This product is not a toy.
- Do not disassemble, repair, or modify the earphones and charging case.
- Do not store the earphones in extreme temperatures, this can shorten the battery life and may affect the headphones.
- Do not place product in or near fire to avoid danger, as it uses a lithium battery.
- Avoid using the indicator close to the eyes of children or animals.
- Do not use earphones during a thunderstorm to avoid irregular function and increased risk of electric shock.
- Do not use harsh chemicals or strong detergents to clean the earphones. Keep the earphones and charging case dry.
- Avoid dropping the earphones and the charging case as it may cause damage to the product.

**IMPORTANT!** Listening at high volume for long periods of time can result in long-term hearing damage. For your safety, do not use headphones in situations where an inability to hear surrounding noise may present a danger to yourself or others.

#### INFORMATION ON DISPOSAL FOR USERS OF WASTE ELECTRICAL & ELECTRONIC EQUIPMENT (PRIVATE HOUSEHOLD)

This symbol on the products and/or accompanying documents means that used electrical and electronic products should not be mixed with general household waste. For proper treatment, recovery and recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis. Alternatively, in some countries you may be able to return your products to your local retailer upon the purchase of an equivalent new product. Disposing of this product correctly will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



[www.otltechnologies.com](http://www.otltechnologies.com) | [info@otltechnologies.com](mailto:info@otltechnologies.com)

Made in PRC

Oceania Trading Ltd/OTL Technologies  
 1B Yukon Road, London SW12 9PZ, UK  
 Hullenbergweg 278-308, 1101 BV Amsterdam, Zuid-oost, NL