
Keyboard instruction

Please read the instructions carefully before use



Keyboard connection operation:

1. Turn on the power supply, and the green indicator light will be lit for one second (if the instruction is red, please charge in time).

Press the matching key "Fn+C/©" for 2 second, the Wireless indicator lights flicker into the pairing state, and the effective time is about 120 seconds.

Open the Wireless search function of the external device, click the "Wireless Keyboard" searched.

After the pairing is successful, the indicator lights go out, and you can use the keyboard.

2. If there is no operation in 10 minutes, the keyboard will go to sleep state and wait for 2~3 seconds by any key to wake up.

Three-channel Bluetooth keyboard connection operation:

1. Turn on the power supply, the green indicator lights for 1 second (if the indicator is red, please charge in time)

Pressing the matching key "Fn+C/ a "above 2 seconds, the Wireless indicator lights flicker into the pairing state, and the effective time is about 120 seconds.

Open the Wireless search function of the external devices, click the "Wireless Keyboard" searched.

After the pairing is successfully, the indicator lights go out, the first device is connected by default and you can use the keyboard.

2. Pressing Fn+ $\widehat{2}$ or $\widehat{3}$, then pressing the matching key "Fn+C/ " above 2 seconds, the Wireless indicator lights flicker into the pairing state, and the effective time is about 120 seconds. Open the Wireless search function of the external devices, click the "Wireless Keyboard" searched. After the pairing is successful, the indicator lights go out, and you can use the keyboard.

- 3. If there is no operation in 10 minutes, the keyboard will go to sleep state and wait for 2~3 seconds by pressing any key to wake up.
- 4. Pressing Fn+ $\widehat{5}$ or $\widehat{5}$ or $\widehat{5}$ to switch the keyboard between three-channel devices. When switching, the Bluetooth light up, indicating that the switch is completed.

Disconnect the keyboard connection:


* If you want to break the connection between keyboard and device, please clear the pairing information in the device, or turn off the keyboard power directly.


Electricity indicator:

* If the power indicator light is red slowly, the power is low, please charge it in time, the red light is bright when charging. When the indicator is green, it is full, please disconnect the charging power to ensure safety.

Shortcut function key: Please note that the function key only works under the corresponding operation interface; If the function key is blue, please press Fn key combination to use; Due to external device or system update, there may be some inconsistency between individual function keys and instructions. If this happens, please refer to the real object.


Refer to the function key icon for instructions:





Please refer to the following instructions according to the actual functions of the

purchased products: (Partial product support)



Basic parameters: (part of the parameters are objective factors will vary).

| Working Voltage: | 3.0V~4.2V | Working Current: | ≤ 3.0mA |
|--------------------|-----------------------|-----------------------|-------------|
| Working Time: | ≥80 Hours | Low Voltage Alert: | 3.0~3.3V |
| Sleeping Current: | ≤0.3mA | Battery Standby Time: | ≥100 Days |
| Battery Capacity: | ≥150mAh | Keystrokes: | 50g-70g |
| Keyboard Lifetime: | 300 Million Times | Charge Input: | 5V === 1A |
| Connect Distance: | ≤10m | Charging Time: | 2~3 Hours |
| Charging Current: | ≤200mA | Awaken Time: | 2~3 Seconds |
| Charging Port: | Micro USB (or Type-C) | Working Temperatur: | 14°F-131°F |
| Matching Password: | No | - | |

Maintenance and warning:

- * Do not squeeze or twist, clap the keyboard.
- Do not scan the microwave and get away from the magnetic field.
- Away from the liquid and used in a dry environment.
- * Clean the keyboard with soft cloth, do not turn off the power for a long time.
- * Other routine maintenance of electronic products.

Common connection Troubleshooting:

- * Make sure the power is turned on and the battery is sufficient.
- * Make sure that the keyboard is within the range of working distance.
- * Make sure that the Wireless related function of the device has been opened.
- * Make sure that the keyboard and the device have been paired.
- * Clear device pairing record and turn off Wireless function; re match.
- * Please do not connect multiple Bluetooth keyboards at the same time; if necessary, please connect one by one.
- * Please try to change charging cable if repeated failure to charge.
- ** This product will not be updated in time for continuous product improvement. If there is any discrepancy, please refer to physical products.

Touch the trackpad: Different operating system, gesture command will be different, please refer to the actual situation of the product.

One Finger

Left-click(customized): Tap with single finger to click Slide the pointer:

Move with single finger

Double Fingers

Switch windows: Slide your fingers from right to left with both fingers



Switch windows: Slide your fingers from left to right with both fingers

Three Fingers



Open the recently used windows: (Switch back to the previous application windows)Three fingers moving down at the same time



Return to the home page: All three fingers moving up at the same time.

Four Fingers



Screenshot: Tap with four fingers