

FOR BATTERY REPLACEMENT

the power switch off, Open battery compartment
the bottom of the unit. Replace AAA battery.

BATTERY NOT INCLUDED.

complete guide on usage, battery replacement
and cleaning details, see instructions inside.

Specifications

Material: Main Body-ABS+PC Cutter Head-Stainless steel
Battery Capacity: 1xAAA
Input: 1.5V/1A
Output: 0.7W

