

Children's fun Camera

Cautions for Battery Use:

1. No power supply above recommended value should be connected.
2. Wire and outer skin must be carefully checked before charging. If damaged, please stop using!

Power Adapter Requirements: DC 5V 400/1000mAh

Attention:

1. Children aged 0-6 years old should use this product under parents' accompany;
2. Small parts can not be swallowed ;
3. Do not put the product near fire ;
4. The packing contains important information. Please keep it properly!

 All product outward appearance, the color take the material object as, the picture only supply the reference!

Interpretation owned by our company!



ROHS



Made in China