

MOJOGEAR

SMARTPHONE & TABLET MOUNT WITH COLD SHOE MOUNT

SKU: MG-31



HOW TO SWITCH BETWEEN SMARTPHONE AND TABLET MODE?

Press the knob on top of the clamp. At the same time, pull to enlarge the clamp and use it in tablet mode.

Press the knob again to lock the clamp in smartphone mode.

HOW TO MOUNT AN ACCESSORY?

You can use the cold shoe mount on top to mount a microphone, LED light or other accessory with cold shoe.

MOJOGEAR

MOJOGEAR develops high-quality products for smartphone filmmakers, mobile journalists and everyone else who wants to get the most out of their phone or camera. MOJOGEAR is proudly based in The Netherlands.

All MOJOGEAR products are covered by a 2-year warranty.

If you have any questions or feedback, please let us know at support@mojogear.eu. We'd love to hear from you!

