

playmobil®

Princess



70447



WARNING: CHOKING HAZARD






Small parts. Not for children under 3 years.



"Ne concerne que les USA"





Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!




Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.


1


































































14













15































22







23

























30 66 3044




2x 30 07 4383




2x 30 07 4363

30 46 8332



30 46 8322




2x 30 07 4373



30 07 4633




30 64 5816




2x 30 07 4523




30 07 4553



30 07 4353



30 07 4583




30 07 4543



2x 30 07 4463



30 22 8842



30 22 8862




30 07 4563




30 51 5500



30 22 8892



30 03 5782




30 51 9550



30 46 7392




30 07 4593



30 51 1333




30 46 7222




30 51 1363




30 03 5672




30 51 9490



30 80 0336



30 80 0346



30 80 0356



3x 30 20 6790



30 28 6850



2x 30 03 3892



30 66 7790



5x 30 21 4612



2x 30 66 7780



5x 30 25 7510



3x 30 28 6720



5x 30 07 4393



2x 30 66 7770



30 67 4770



30 07 4403



3x 30 07 4303




30 03 5832



4x 30 07 4573



30 07 4423



5x 30 61 1292



30 25 7720



30 243 940



30 22 8962



30 46 6560



2x 30 07 4473




3x 30 07 4293




2x 30 07 4493



30 07 4643



30 22 8992



30 07 4453



30 20 9440



30 07 4413




30 07 4333



30 25 6602




30 20 7240



2x 30 07 4503




2x 30 22 8772



30 60 1462




30 80 0316



30 07 4323



30 22 8782




30 64 5786




30 64 5796




2x 30 22 8792



30 51 9450



30 51 9570



2x 30 07 4283



3x 30 20 6860



30 46 6570



2x 30 07 4603



3x 30 07 4513



9x 30 20 6880



30 22 1290



3x 30 07 4033



30 21 4422



30 07 4343



30 25 3120



7x 30 03 2920



30 07 4433



3x 30 22 8732



30 25 8580



30 20 6900



30 25 8570



30 65 8822




2x 30 07 4213




2x 30 22 9302



3x 30 22 9312



30 51 9680



2x 30 07 4623



30 07 4533



2x 30 64 5806



3x 30 24 8370



30 07 4613



2x 30 07 4243



2x 30 09 2110



2x 30 24 1583



2x 30 07 4313



30 25 6820




30 25 6730



30 22 8742



30 51 5572




30 51 5562



3x 30 05 4222



15x 30 23 3752



30 51 9530



30 61 1312



6x 30 61 3370



30 80 0326



4x 30 25 7473



2x 30 07 4483



2x 30 07 4443



30 22 8752



2x 30 07 4263



4x 30 05 8550



2x 30 22 8812



30 22 9462



30 20 7230



2x 30 22 9032




30 22 9512




11x 30 25 0740



5x 30 25 0720



6x 30 25 0000



11x 30 25 5502



6x 30 03 5582



6x 30 03 5602



12x 30 04 0703



6x 30 05 0952




5x 30 25 8720



5x 30 25 2810



80x 30 03 6600



192x 30 09 6900



Serviceadressen finden Sie in allen PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos PLAYMOBIL.

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāymō-bēēl

Family Fun



70437

70440

70439

70436



70274

70438



70434

70435

Princess



©2020 geobra Brandstätter Stiftung & Co. KG
Brandstätterstr. 2-10 • 90513 Zirndorf, Germany
No. 30 80 2766 05.20



70448



70451



70455



70452



70450



70449



70447



70453



70454

