

# Corresponding Model

Please find the corresponding model behind the iPad

\*Please purchase after confirming the model  
Or contact customer service to inquire !



iPad	Model
2018 iPad Pro 11	( A1980 / A2013 / A1934 / A1979 )
2020 iPad Pro 11	( A2228 / A2068 / A2230 / A2231 )
2018 iPad Pro 12.9	( A1876 / A2014 / A1895 / A1983 )
2020 iPad Pro 12.9	( A2229 / A2069 / A2232 / A2233 )
iPad 10.2 (2019)	A2197 / A2198 / A2200
iPad 10.2 (2020)	A2270 / A2428 / A2429 / A2430
iPad Air 2	( A1566 / A1567 )
iPad 9.7" 2017(5th)	(A1822 / A1823)
iPad 9.7" 2018(6th)	(A1893 / A1954)
iPad Air 3 2019(10.5")	A2152 / A2123 / A2153 / A2154
iPad Pro 10.5"	A1701 / A1709
iPad Mini 4 (7.9" )	A1538 / A1550
iPad Mini 5 (7.9" )	A2133 / A2124 / A2126 / A2125