



- ① Flash Light ② Rear Camera ③ Speaker
 ④ Power Button / Front and Rear Camera Switch
 ⑤ USB Slot ⑥ Front Camera ⑦ Indicator
 ⑧ Up Button ⑨ Down Button / Fill Light Button
 ⑩ Home / Video / OK Button ⑪ Setup ⑫ Mode
 ⑬ Volume Up Button ⑭ USB Slot ⑮ Microphone