

Fold



When you hear a "click" sound, the legs are fixed.

Unfold



Push the indicated part down to fold the table.