



A. Major parts list



Major parts list			
1.	rubber grip	6.	brake pad
2.	handlebar	7.	PU wheel
3.	lock buckle	8.	pedal bracket
4.	handlebar stem	9.	pedal
5.	non-slip mat	10.	front bracket
11.	upper snap joint	12.	under snap joint

Installation Instructions

1. Push the under snap joint and aim at the snap joint hole on the pedal, then insert the handlebar stem into the hole of the pedal.
2. Loosen the lock buckle, then pull the handlebar upward. When the snap joint pops, lock the buckle.



How to use

Hold the rubber grip handlebars. Put one foot on the scooter, the other foot on the ground. Push off the ground to move the scooter forward.

Warning

Please retain instructions for future reference.