CLAIM YOUR 1 YEAR WARRANTY

Your product is **not yet warranted** for a period of 12 months from the original date of purchase under the terms of conditions of this warranty.


To claim your 1 year warranty, please go to www.trylumime.com/claimwarranty

The 1 year warranty covers manufacturing defects. Proof of purchase is required. The warranty against defects does not cover loss, damage, breakage, changes in appearance, kinks, or the gradual degradation of all or part of the goods due to normal wear, mishap, careless handling, improper use, or use outside of our care instructions

LumiMe®

Marka.

Lantern Lamp



Quickstart Guide

Use Marka wherever, however you like.

2 Turn on Marka by ticking the touch button.









5 Turn Marka in any direction.

4 Buckle up Marka.



360 adjusting the lighting angle by revolving.

First, aiming at the denting groove with the salient point,

press the top and bottom cap with both hands. and then revolve it clockwise

in the meantime to make sure the salient point snap

into place.

3 Open Marka by twisting.



hand anti-clockwise.

tube into the state of lantern.

Touch switch

Adjust the 3-level brightness by ticking the touch button

Charge outlet, DC 5V

2. pull up the middle extension

For any questions please visit our website or contact our customer service.

Global

www.trylumime.com info@trylumime.com The Netherlands www.lumime.nl info@lumime.nl

Social Media

- facebook.com/lumime.original
- instagram.com/lumime.original

Product of Freebird Products®

twitter.com/lumime.original