



---

# CGH1020D - CGH1030D

## ALL DAY CONTACT GRILL

Instructions for use. Keep these instructions

Visit [www.delonghiregistration.com](http://www.delonghiregistration.com) to register your product

Visit [www.delonghi.com](http://www.delonghi.com) for a list of service centers near you.

### ELECTRIC CHARACTERISTICS

120 V~ 60 Hz 1800 W

## GRIL CONTACT

Mode d'emploi . Conservez cette notice

Visitez [www.delonghiregistration.com](http://www.delonghiregistration.com) pour enregistrer votre

produit en ligne.

Visitez [www.delonghi.com](http://www.delonghi.com) pour y voir une liste des centres de

réparation proches de chez vous.

### CARACTÉRISTIQUES ÉLECTRIQUES

120 V~ 60 Hz 1800 W

## PARRILLA DE CONTACTO

Repase y guarde estas instrucciones.

Lea cuidadosamente este instructivo antes de usar su aparato.

Visite [www.delonghiregistration.com](http://www.delonghiregistration.com) para registrar su producto

en línea.

Visite [www.delonghi.com](http://www.delonghi.com) para ver la lista de centros de servicios

cercanos a usted.

### CARACTERISTICAS ELECTRICAS:

120 V~ 60 Hz 1800 W



---

The DeLonghi logo is enclosed in a black oval with a white border. The word "DeLonghi" is written in a bold, black, sans-serif font, with the "D" being significantly larger than the other letters.

EN


page 4

FR

page 8

ES

pág. 12



For more recipes:  
(free download)



De'Longhi Recipes

-----[delonghi.com](https://www.delonghi.com)

