

METAL

REMOTE CONTROL HIGH SPEED CAR

FULL FUNCTION

M
REN
HIGH


2. Non-rechargeable batteries are to be removed from the toy before being charged (if removable).
3. Rechargeable batteries are only to be charged under adult supervision (if removable).
4. Rechargeable batteries are only to be charged under adult supervision (if removable).
5. Different types of batteries or new and used batteries are not to be mixed.

R/C BATTERY DESCRIPTION



Open the battery cover on the remote control, use 2x1.5V "AA" batteries (not included), mount the remote control button battery cover. Follow the polarity of the battery compartment tip correctly into the battery, and avoid danger!

DIRT BIKE BATTERY DESCRIPTION



USE 1x3.7V BATTERY PACK (INCLUDED) OPEN THE BATTERY COVER, REMOVE THE BATTERY PACK CONNECT CHARGE LINE CHARGE.

USB charging cable, USB charging cable, please connect computer USB port or other 5V output port.

BATTERY SAFETY INFORMATION:

1. Car use 1x3.7V rechargeable batteries, remote control with 2x1.5V "AA" non-rechargeable battery.
2. Non-rechargeable batteries are not to be recharged.
3. Rechargeable batteries are to be removed from the toy before being charged (if removable).
4. Rechargeable batteries are only to be charged under adult supervision (if removable).
5. Different types of batteries or new and used batteries are not to be mixed.
6. Only batteries of the same or equivalent type as recommended are to be used.
7. Batteries are to be inserted with the correct polarity.
8. Exhausted batteries are to be removed from the toy.
9. The supply terminals are not to be short - circuit - ed. Toy appliances in use successfully in the process, you should periodically check the wires, plugs. Shell and other parts for damage, found damage should discontinue use until the repair is intact.



Made in China

<p>NOT BURNABLE FROM CHILDREN'S TOYS DUE TO SMALL PARTS</p> <p>غير قابل للاحتراق من ألعاب الأطفال بسبب الأجزاء الصغيرة</p> <p>NOT FOR CHILDREN UNDER 3 YEARS</p> <p>غير مناسب للأطفال تحت سن 3 سنوات</p> <p>CHOKING HAZARD-Small parts. Not for children under 3 years.</p>	<p>PELIGRO DE ASFIXIA -CONTIENE PARTES PEQUEÑAS NO RECOMENDADO PARA NIÑOS MENORES DE 3 AÑOS</p>	<p>متى وشك للاستهلاك والتلفير الخطيرة</p> <p>Tested according to international standards</p>
---	---	--

No.:33811A



SPECIFICATION & COLOURS OF CONTENTS MAY VARY ILLUSTRATIONS.

FULL FUNCTION