



**1. OPEN THE BATTERY COVER BY  
SCREW,PUSH OUTWARD THE  
BATTERY COVER**



**2. CONNECT THE BATTERY AND UPS**