


ATTENTION ADULTS:

Remove all packaging material and dispose them before giving toys to child.
Retain the packaging for future reference as they contain important information.
Final product may vary slightly.

BATTERY SAFETY INFORMATION:

1. Product require 2x1.5V (AAA) battery.
2. Battery is to be inserted with the correct polarity.
3. Exhausted battery is to be removed from the product.
4. The supply terminal is not to be short-circuited.
5. Non-rechargeable battery is not to be recharged.
6. Dispose of battery safely.
7. Do not dispose of this product in a fire. The battery inside may explode or leak.
8. Battery should be changed by adults only.
9. Battery unused for a long time need to be removed from the product.



Use a screwdriver to remove the battery cover.
Place new battery into the battery compartment and replace the battery cover.

USE 2x1.5V "AAA" (BATTERY AND SCREWDRIVER ARE NOT INCLUDED)

SPECIFICATIONS, COLOURS AND CONTENTS
MAY VARY FROM ILLUSTRATIONS.



No.:188-7

A B C

Made in China