

QUICK START GUIDE

BC

TUNE750BTNC



WHAT'S IN THE BOX




POWER ON & CONNECT



2s

POWER ON AND AUTOMATICALLY ENTER PAIRING MODE




CHOOSE "JBL TUNE750BTNC" TO CONNECT

MANUAL PAIRING





>5s

MANUAL PAIRING MODE



CHOOSE "JBL TUNE750BTNC" TO CONNECT

BUTTON COMMAND



>2s

>2s

>2s

>2s


>2s

>2s

WIRED LISTENING



MULTI-POINT CONNECTION




>2s

ENTER PAIRING MODE WITH THE 2ND DEVICE


* (MAXIMUM 2 DEVICES)

- 1 TO SWITCH MUSIC SOURCE, PAUSE THE MUSIC ON THE CURRENT DEVICE AND SELECT PLAY ON THE 2ND DEVICE.
- 2 PHONE CALL WILL ALWAYS TAKE PRIORITY.
- 3 IF ONE DEVICE GOES OUT OF BLUETOOTH RANGE OR POWERS OFF, YOU MAY NEED TO MANUALLY RECONNECT THE REMAINING DEVICE.
- 4 SELECT "FORGET THIS DEVICE" ON YOUR BLUETOOTH DEVICES TO DISCONNECT MULTI-POINT.




1ST BLUETOOTH DEVICE

CHOOSE "JBL TUNE750BTNC" TO CONNECT



2ND BLUETOOTH DEVICE

CHARGING



CHARGE

2HR

LED BEHAVIORS

