





A	B	C	D	E
38x 	44x 	44x 	32x 	8x
F	G	H	I	J
4x 	2x 	14x 	14x 	6x
K	L	M	N	O
2x 	12x 	2x 	6x 	4x
P	Q	R	S	
4x 	4x 	1x 	8x 	
T	U	V		







2







3




4







9




10





11



13




12



ASSEMBLING INSTRUCTIONS

TYPE : NEVADA TV RACK

15



14

