

# HOW TO REPLACE FILTER ELEMENT



The filter element is easy to be replaced. It is recommended to replace the filter element **every 2-3 months**.



## STEP 1

Unscrew the handle shell



## STEP 2

Pull out the old filter element



## STEP 3

Install a new filter element



## STEP 4

Screw the handle shell

**GET NEW FILTERS ON OUR WEBSITE**

[SANILIVINGHOMESPA.COM](http://SANILIVINGHOMESPA.COM)

Saniliving