

#### BATTERY INSTRUCTIONS

Only Adults should replace batteries.  
Locate the switch on the bottom of toys and make sure it is off.  
Remove all used batteries from inside the compartment.  
Dispose of used batteries properly.  
Cut the polarity (+/-) of the new battery and place properly inside the compartment.

**WARNING:** Children under 36 months should not use this product.  
This product contains small parts, eating can lead to suffocation.  
**WARNING:** This is a generic food with warm water and mild detergent to clean the play set accessories for safety.  
The toys by adults assembled. Read the instructions on the package diagram.  
Specifications, colors and contents may be related to differences in kind. Check please in kind information on the packaging should be retained for future reference.



#### BATTERY (continued) and LABELING

Use alkaline batteries recommended.  
Do not use rechargeable batteries.  
Non-rechargeable batteries are not to be recharged.  
Do not mix old or new batteries.  
Do not mix alkaline (standardization size) or rechargeable (over-voltage) batteries.  
Only batteries of the same or equivalent type as recommended are to be used.  
Batteries are to be inserted with the correct polarity.  
Exhausted batteries are to be removed from the toy.  
The supply terminals are not to be short-circuited.  
Please keep this instruction for future reference.  
Remove batteries from the product before extended storage.  
Please take note that the product may vary any time for colour and the illustration of the package.



USE ONLY 5AA/KNV  
BATTERIES (Not Included)

Copyright all rights reserved



Copyright all rights reserved

**WARNING:**  
**CHOKING HAZARD** -Small parts.  
Not for Children under 3 years.

